

HighPure Deluxe Reverse Osmosis System

Installation, Operation and Maintenance Manual



IMPORTANT: Fill in Installation & Start-Up Checklist and the Operation Log Sheet for Future Reference

Commercial/Industrial Reverse Osmosis System

Deluxe 1,800 to 12,240 GPD

Applications

- Ingredient water
- High purity rinse water for plating, electronics and automotive
- Ion exchange pretreatment
- Whole building water loop
- Boiler feed water
- Vapor/Steam generators
- Manufacturing process water
- Laboratory and analytical testing
- Drip irrigation
- Horticulture/floriculture/green houses
- Misting and humidification systems
- Cooling tower make-up water
- Community water vending including RV and manufactured home parks and marinas

Features

- Nominal salt rejection 95–99%
- Energy efficient, low pressure membranes.
- High efficiency stainless steel Berkeley® multistage pump
- Genuine PENTEK® prefilter housing with 20" Versaflex™ 5 micron Pentair Industrial technology prefilter
- Stainless steel membrane housing, control panel, hardware and coated membrane brackets
- Ashcroft® prefilter, postfilter, primary and final pressure gauges
- Blue-White® permeate, concentrate and recycle flow meters with integrated recirculation control
- Industrial grade solenoid valves

No part of this document may be copied or reproduced in any form or by any means without the prior written permission of Pentair Water Commercial & Industrial Purity Solutions (CIPS). Pentair believes the information and data contained herein to be accurate and useful. The information and data are offered in good faith, but without guarantee, as conditions and methods of use of our products are beyond our control. Pentair Water CIPS makes no warranties with respect to this documentation. Information in this document is subject to change without notice. Pentair Water CIPS shall not be held liable for technical or editorial errors or omissions that may appear in this document; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this document. Pentair assumes no liability for results obtained or damages incurred through the application of the presented information and data. It is the user's responsibility to determine the appropriateness of Pentair's products for the user's specific end users.

Pentair Water Commercial & Industrial Purity Solutions (CIPS)

Pentair Water CIPS is a global provider of technologies and solutions for a variety of commercial and industrial applications. We offer world class products and systems that combine quality, global branding, application knowledge, and Technical Support to meet our customers' needs anywhere in the world.



Pentair Water
Commercial & Industrial Purity Solutions

Table of Contents

Commercial/Industrial Reverse Osmosis System	3
Installation and Start-up Checklist	6
Important Information	7
Safety, Cautions, & Warnings	8
Installation and Initial Start-up	10
Start-up	17
Membrane Production Capabilities	18
Daily Start-up and Operation	19
Troubleshooting	20
Maintenance	23
General	23
Maintenance and Servicing	23
Replacing Inlet Cartridge Filters	23
TDS Calibration	23
Rebuilding Pump	23
Cleaning the Membranes	24
RO Membrane Fouling and Cleaning	24
Types of Foulants	27
Selection and Use of Cleaning Chemicals	28
RO Membrane Element Cleaning and Flushing Procedures	33
General Storage Procedures for Composite Polyamide ESPA1 RO Membrane Elements	35
Glossary	37
HighPure Deluxe RO System Layout - 1 Membrane	39
HighPure Deluxe RO System Layout - 2 Membrane	40
HighPure Deluxe RO System Layout - 3 Membrane	41
HighPure Deluxe RO System Layout - 4 Membrane	42
HighPure Deluxe RO System Layout - 5 Membrane	43
HighPure Deluxe RO System Layout - 6 Membrane	44
Silt Density Index (SDI)	45
HighPure Deluxe Specifications	47
Controller Specifications	48
Ordering Information	49
Appendix A - Temperature Correction	51
Appendix B - Conductivity, Resistivity and TDS Conversion Chart	52
Appendix C - Water Corrosivity	53
Limited Warranty	54
Operation Log Sheet	55

Tables

Table 1: Concentrate vs Recycled at Standard Recoveries Table.....	17
Table 2: Operation Trends	25
Table 3: RO Troubleshooting Matrix	26
Table 4: Hydranautics Recommended Chemical Cleaning Solutions.....	29
Table 5: Hydranautics Recipes for Cleaning Solutions.....	31
Table 6: Hydranautics pH and Temperature Limits for Cleaning	31
Table 7: Cleaning and Flushing Flow Rates per RO Pressure Tube	31
Table 8: Cleaning Solution Volume Requirement per RO Element.....	32

Figures

Figure 1 - RO System Controller LED Layout	10
Figure 2 Deluxe RO Circuit Board	11
Figure 3 Machine Feature Identification Front.....	12
Figure 4 Machine Feature Identification Back	13
Figure 5 Position of Membranes.....	14
Figure 6 Union O-ring	15
Figure 7 CIP Connections	32

- Use this form to record initial system hardware and site conditions.
- Retain a copy for future reference.
- Fill in the appropriate data (if available).
- Checklist data should be collected and logged on this form for each system installed.

Installation Date: _____

Installer: _____

Installation Site: _____

Application: _____

System Model: _____

Serial Number: _____

Water Source: _____

Pretreatment Installed: _____

Clean in Place Installed: Yes _____ No _____

Feed Water Analysis: _____

Installation Address: _____

Page 6

IMPORTANT! READ THIS FIRST

Read this service manual thoroughly before first use.

- Check the HighPure RO System periodically to ensure proper operation (i.e.: flushing, flow rate, pressure drop, etc)
- Do not allow the HighPure RO System to be exposed to freezing temperatures. Freezing will damage the system.
- Ensure the membrane does not dry out. Opened membranes should be preserved with a 0.1% sodium bisulfite solution.
- Keep this service manual near the HighPure RO System for future reference.
- The HighPure RO System is intended to treat only potable quality water. It is not intended as the primary treatment of water from a source that is contaminated, such as from radon, pesticides, insecticides, sewage, wastewater, seawater or brackish water.
- Use lubricants (such as glycerin) sparingly.
- A leak detection device must be used to detect water leaking onto the floor.
- In addition to meeting codes, laws, and regulations, the user should understand the care and maintenance of the HighPure RO System. Please read the information found in this service manual.

NOTE: Read all safety precautions before installing, operating, or servicing the HighPure RO System.




IMPORTANT PLEASE READ:


- The information, specifications and illustrations in this manual are based on the latest information available at the time of printing. The manufacturer reserves the right to make changes at any time without notice.
- This product should be installed by a qualified electrical and plumbing professional.
- This unit is designed to be installed on potable water systems only.
- This product must be installed in compliance with all local, state, provincial, and municipal plumbing and electrical codes and regulations. Permits may be required at the time of installation.
- Do not install the unit where temperatures may drop below 35°F (2°C) or above 104°F (40°C).
- Do not place the unit in direct sunlight.
- Do not strike any of the components.
- Misapplication of this product may result in failure to properly condition water, or damage to product.
- In some applications local municipalities treat water with Chlorine and or Chloramines. High Chlorine and or Chloramine levels may damage system components.
- Correct and constant voltage must be supplied to the controller to maintain proper function.
- Proper pretreatment must be installed before the RO system to meet the minimum water quality requirements. Failure to meet these requirements will void the warranty.
- The correct prefilter must be used and changed according to the instructions or the warranty will be void.

Safety, Cautions, & Warnings

Safety

- The HighPure RO System must be wired according to local electrical codes to prevent the possibility of electrical shock.
- The HighPure RO System has been designed and tested to offer reliable service when installed by a qualified professional and operated and maintained according to the instructions in this service manual.
- Any corrosive chemicals used in the HighPure RO System are to be for membrane cleaning only. Other chemicals may damage the RO System. See section on cleaning.
- Do not install the HighPure RO System if it has been damaged or dropped.
- Disconnect the HighPure RO System from the power source before performing any service or maintenance.
- If membrane elements cannot be loaded into the system upon delivery, store elements in a cool dry location out of direct sunlight. Do not allow the elements to freeze.
- Always shut off the water flow and release water pressure before cleaning or maintaining the HighPure RO System or changing cartridges.
- The HighPure RO System is intended for indoor use only. The controller must not be exposed to weather elements.

	<p>CAUTION</p> <ul style="list-style-type: none">• Minimum water pressure 40 psig (2.8 Kg/cm²).• Maximum water pressure 80 psig (5.6 Kg/cm²).• Minimum water temperature 35°F (2°C).• Maximum water temperature 104°F (40°C).• Disconnect all power sources before servicing.
---	--

	<p>WARNING</p> <p>The system MUST be depressurized before removing any connections for servicing.</p>
--	---

Lubricants

- At no time should petroleum based lubricants (oil, grease, or petroleum jelly) be used when lubricating interconnector O-rings, end adapter O-rings or the membrane element brine seal. An acceptable lubricant is glycerin.
- Use a mixture of 50% glycerin in water to lubricate O-rings and brine seals.

NOTE: Permeate flow for individual membrane elements may vary + or -15%. All membrane elements are supplied with a brine seal, interconnector, and O-rings. Elements are enclosed in a sealed polyethylene bag containing less than 1% sodium meta-bisulfite solution and 10% propylene glycol in a cardboard box.

Safety, Cautions, & Warnings

Permeate Valve Operation

Install a permeate check valve between the storage tank and permeate line from the RO system. The membrane element shall not, at any time, be exposed to permeate back pressure (where permeate static pressure exceeds concentrate static pressure). There shall be no permeate back pressure at shutdown. At no time during operation of a membrane element system should the permeate valve(s) be closed. Closing the permeate valve during any phase of operation causes a pressure differential across the tail end of the system and will likely result in irreparable damage to the glue lines of the tail element(s). This damage will cause immediate increase in TDS passage through the RO membrane.

NOTE: The Composite Polyamide type of RO membrane elements supplied must not be exposed to chlorinated water under any circumstances. Any such exposure will cause irreparable damage to the membrane. Absolute care must be taken following any disinfection of piping or equipment or the preparation of cleaning or storage solutions to ensure that no trace of chlorine is present in the feedwater to the RO membrane elements. If there is any doubt about the presence of chlorine, perform chemical testing to make sure. Neutralize any chlorine residual with a sodium bisulfite solution or activated carbon, and ensure adequate mixing and contact time to accomplish complete dechlorination. Dosing rate is 1.8 to 3.0 ppm sodium bisulfite per 1.0 ppm of free chlorine.

Presence of Total or Free Chlorine in Feed Water of Thin Film (Polyamide) Membrane Elements

At no time should there be a Total or Free Chlorine residual in the feed water. Even very low levels of chlorine/ chloramine in the feed stream will result in irreparable oxidation damage of the membrane. Therefore, operators should ensure that oxidant does not enter the RO system. To ensure that membranes are not harmed by oxidant, Pentair recommends that the feed to the RO system is equipped with an ORP (Oxidation-Reduction Potential) meter. The feedwater can then be continuously monitored for the presence of oxidant. The ORP meter reading should always be below 180 mV. If it exceeds 180 mV, the plant operator should receive a warning that a dangerous level of oxidant is getting to the membrane and should take action, such as changing the carbon tank or adding or increasing the dose of sodium bisulfite (SBS), to reduce the oxidant concentration. If the ORP value reaches 200 mV, the plant should be shut down until the oxidant concentration can be reduced to a safe value (ORP <180 mV). Please contact your system provider for various methods of removing Total or Free Chlorine prior to the membrane system.

NOTE: The oxidative effects of Chlorine are strongly catalyzed in the presence of metals such as chromium, iron and manganese. If transition metals are present, it is recommended that there be NO Chlorine in the feed water.

Permeate Water Production During 5 Minute Flush

Some permeate water will be produced during the systems 5 minute flush. Size the storage tank appropriately or provide for a permeate overflow on the tank to prevent damage to the system.

NOTE: Maximum permeate back pressure must not exceed 60 psi.

Installation and Initial Start-up




Figure 1 - RO System Controller LED Layout

Installation and Initial Start-up




Figure 2 Deluxe RO Circuit Board

Installation and Initial Start-up




Figure 3 Machine Feature Identification Front

Installation and Initial Start-up




Figure 4 Machine Feature Identification Back

Installation and Initial Start-up

1. Locate machine with access to power, water supply piping, drain and space to service unit. Use the leveling feet to level the system. Be certain to allow room for maintenance and 46 inches of clearance above the membrane housing for changing of the RO membranes. If 46 inches of clearance is not available the membranes are changed by removing the membrane housings. Be certain to leave room for a person to work behind the unit.
2. Remove pipe assemblies at the top of the housings. Loosen the end clamps and remove the end caps using a slide hammer or a tee.
3. Load membranes into pressure vessels according to the concentrate flow direction. Note the position of the brine seal placement on the membrane (Figure 5). Each housing has an arrow indicating the direction of flow for that housing (Figure 5). The brine seal must be at the water inlet of the housing.



CAUTION

When inserting the membranes with the brine seal end first, it is possible for the brine seal to flip or bend backwards. To help avoid this the walls of housing should be lubricated with glycerin.




Figure 5 Position of Membranes

Some HighPure models may have pipe assemblies removed for protection during shipment (Figure 3). These assemblies need to be removed and reconnected after the membranes are installed. Proper placement of the union O-rings is required prior to tightening the union connections (Figure 6).



CAUTION

Use glycerin on O-rings. Make certain O-ring is seated in groove. Do not overtighten unions. Hand tighten only.

Installation and Initial Start-up




Figure 6 Union O-ring

4. If using external tank level, and pretreat lock-out switches, connect "normally open" switches to tank level (TF), and pretreat lock-out (PF) on appropriate terminals on circuit board for non-powered, dry contact control (Figure 2). The pretreatment inputs must be wired in parallel. The terminals are located in the upper right corner of the control panel box when viewed from the back. Use small gauge, 2 conductor wire connections, see Figure 2. The back of the control panel will need to be removed and the power to the system turned off. Confirm that the two input signals (tank level switch and pretreat switch) are all normally open dry contacts. Systems with pretreatment can have a normally open contact switch wired to the control. This switch should operate (close) when the pretreatment device is out of service. This switch must not supply voltage. Be sure to coil and leave some slack wire inside the enclosure.

NOTE: Installing the Clean-In-Place (CIP) Hardware. CIP valves and piping are not included with the HighPure System. Valves and piping are purchased and installed separately. When installing CIP valves a three-way valve should be installed on the feed water line to the RO unit. Tees on the permeate and concentrate lines should use two-way valves. The valves should allow circulation of cleaning chemicals through the RO unit and back to the CIP tank.

NOTE: The system requires sufficient pressure to operate and will shut down if inlet pressure falls below 7 psi.

NOTE: Maximum permeate backpressure is 60 psi.

5. Use only Teflon tape to connect water piping to RO system. Connect water supply piping that has sufficient flow and pressure to operate at prescribed permeate production and concentrate flow to drain. Refer to Specification Table for requirements.



CAUTION

Make certain all pretreatment equipment has been rinsed/purged of carbon fines and other materials. Pretreatment equipment that cycles and may allow untreated water to pass must be wired by normally open, dry contacts to the pre-treatment terminals on the control board. Failure to do so will cause equipment failure and possibly void any warranty.

6. Connect concentrate drain piping with appropriate air-gap according to national, state and local codes. Drain pipe must be suitable to handle concentrate flush flows. Concentrate flush is approximately 12 gpm for 1-3 membrane systems and approximately 25 gpm for 4-6 membrane systems for 5 minutes at shut-down. The drain piping and reservoir if applicable should be sized appropriately.
7. Connect temporary permeate piping directed to drain. Make certain to have an air gap between the piping and the drain. The initial flushing of the permeate system should go to drain to remove any residual disinfectant from the RO membranes.



WARNING

To reduce the chance of contamination of the RO system a separate (disposable) hose should be used for permeate flushing. This hose must have an air gap at the drain and must be secured.

Installation and Initial Start-up



Preservative Flushing

To protect elements from biological growth and to help maintain performance over time, Hydranautics composite type ESPA1 membranes are stored in a combination of 1% sodium bisulfite and 10% propylene glycol solution. It is therefore advised to flush membranes prior to use to eliminate residual preservatives in the product stream. The standard ESPA1-4040 membrane supplied are stored in the sodium bisulfite and propylene glycol solution.

Once the elements have had the preservatives flushed from them, they would need to have preservatives re-applied for long term storage.

Preservative Flushing during Start-up

Once elements have been loaded and vessels sealed, it is recommended to flush the system to drain with feedwater at design operating pressure for a minimum of 2-24 hours. If the elements are to be used in systems with potable water for drinking, food or requiring ultrapure water, a minimum flushing time of 24 hours is recommended to reduce the TOC concentration to below 50 ppb (assuming zero TOC in the feedwater). Always test permeate after each flush for residual preservative or other critical contaminants.

	<p>WARNING</p> <p>For potable applications using models that are preserved with both sodium bisulfite and propylene glycol, discard the product water for at least 24 hours prior to drinking or using in food applications. Ingestion of the preservative may cause irritation of the gastrointestinal tract, colic, diarrhea, or other similar symptoms.</p> <p>The membrane preservative may be harmful to humans and animals when taken internally.</p>
	<p>WARNING</p> <p>This system produces high purity water that can corrode standard galvanized, copper piping and brass fittings in common piping systems. Use appropriate plumbing materials after system to prevent unnecessary corrosion and contamination of permeate water.</p>

The hose connecting to the storage tank must remain clean to prevent possible contamination of the water storage. Connect permeate piping to storage tank.

8. Unwrap and install Versaflex™ prefilter into the blue housing on the inlet side of the system. Make certain O-ring is in the groove in the sump below the threads and hand-tighten housing into cap. Only use supplied housing wrench to loosen housing, never to tighten.
9. Open water supply to system and confirm prefilter and postfilter pressures. Typical feed pressure is 40-80 psi. Check for leaks. The pressure readings should be the same because the inlet valve is closed. IF the feed pressure is higher than 80 psi install a pressure reducing valve before the system to maintain the proper feed pressure.
10. The power cord is located on the lower left of the control panel when viewed from the back. If using the installed power cord, replace the back panel of the control box. If a longer cord needs to be installed, connect the new power cord to the board first per the circuit diagram Figure 2, AC power for the unit is connected to terminal strip P1. Connect the ground wire of the AC power to P1 (GND). For AC power with a neutral and hot wire, the hot wire connects to P2 (L1) and the neutral wire connects to P3 (L2). For AC power with 2 hot wires, either wire can connect to L1 and L2. Replace the back panel. Make appropriate electrical connections with fused disconnect or Ground Fault Protection. Use 20 amp service 240 VAC, single phase, for the 1 hp 1-3 membrane systems and for the 2 hp 4-6 membrane systems. Turn on the electrical power to the RO system and go through start up procedure.
11. Check all connections for leaks before leaving system.

Read completely before starting.

1. Fully open concentrate control valve by turning counterclockwise (to the left). Never start the system with the concentrate valve closed.
2. To purge air from system. Push power button to START system - wait 4 seconds and push button to STOP. This will prevent the pump from turning on and prevent any damage from high velocity air and water in the system. When the POWER button is pushed, the system will open the inlet solenoid allowing water to flow into system.
3. Allow air to purge from system. Repeat pushing start button and then pushing it again after 4 seconds until air is purged from system and water flows through the concentrate flow meter.
4. Press power and release. After a 5 second delay the pump will start and the green RUN light will come on. If prefilter water pressure is less than 7 psi, the pump will not operate.
5. Slowly close the concentrate valve. The concentrate flow should be set at a level slightly below maximum. Flush for 20 minutes.
6. After the initial 20 minute flush adjust the concentrate valve. The membrane feed pressure will increase. Adjust until pressure is between 100 to 180 psi.
7. Fully open recycle control valve on recycle flow meter by turning counterclockwise (to the left). After air is purged from the system set the recycle flow rate. Make adjustments as needed. See Table 1: Concentrate vs Recycled at Standard Recoveries below for additional information on adjusting the recycle flow. Check to make sure all flowrates are within designed ranges. Adjust accordingly.
8. The permeate flow should run through the temporary permeate piping to a drain for 2 to 24 hours to remove residual sanitizing chemicals. After flushing is complete connect permanent permeate piping to tank. A permeate check valve must be installed between the storage tank and the membrane.
9. Check all flow rates again. Allow tank to fill.
10. Inspect all connections for leaks periodically until storage tank reaches full pressure or level. All Pentair systems are tested for leaks before shipment. Leaks may occur due to vibration in shipping.
11. Check that TDS is at or below designed level. Make appropriate adjustments as needed.
12. Make sure concentrate flush starts when tank full switch is closed. This can be simulated by manually moving the switch. Check that drain flow is appropriate to handle concentrate flush for 5 minutes.
13. Fill out the Installation and Start-up checklist at the front of this manual and the Operation Log Sheet in the back.
14. Verify the correct operation of the pretreatment lockout. Cycle all components and check light on operator panel.
15. Verify the leak detection device works.
16. E-mail or send a copy of the Installation and Start-up Checklist to Technical Support.

Table 1: Concentrate vs Recycled at Standard Recoveries Table

Recovery		33%		50%		60%		75%	
Number of 4" x 40" Membrane	Total Concentrate plus recycle flow (gpm)	Concentrate	Recycle	Concentrate	Recycle	Concentrate	Recycle	Concentrate	Recycle
1 Housing	9.4	2.5	6.9	1.25	8.2	0.8	8.6	0.4	9
2 Housings	9.4	5	4.4	2.5	6.9	1.6	7.8	0.8	8.6
3 Housings	8.3	7.5	0.8	3.75	4.6	2.5	5.8	1.25	7.05
4 Housings	19	10	9	5	14.05	3.3	15.7	1.7	17.3
5 Housings	17.6	12.5	5.1	6.3	11.3	4.2	13.4	2.1	15.5
6 Housings	16.6	15	1.6	7.5	9.1	5	11.6	2.5	14.1
Settings not recommended. Not within range of flowmeter.									


All flows in gpm. Flows based on 1800 gpd/element.

Membrane Production Capabilities

Each membrane is capable of producing "clean" permeate water at a certain flow (gallons per day). The HighPure RO systems use multiple membranes to increase the flow of permeate (clean) water. The information below shows the production guidelines of one 4" x 40" membrane.

Recommended Guidelines on RO Machine Production per 4"x 40" Membrane

Inlet TDS	Flow gpd
<50	2040
50-200	1950
200-500	1900
500-700	1850
700+	1800



NOTE: SDI<1, well water, no colloids present, 77°F (25°C) water. Operating at higher flux rates can limit and affect membrane life, and increase frequency of cleanings. Actual water conditions and levels of contaminants will vary performance. No saturation constituents in the concentrate. Check standard feed water quality requirements for additional information.

For further information contact Technical and Application Support at Tech.SupportCIPs@Pentair.com.

Daily Start-up and Operation

1. Push the **START** button. The pump motor will start after five seconds.
2. Observe the pressure gauges and flow meters. Consult the *Installation and Start-up Checklist* for operating pressures and flow meter settings.
3. Use the concentrate valve to adjust system pressure. Deluxe models have an adjustable flow meter for recycle that can be used to further increase/decrease recovery percentage and change membrane cross flow.
4. Once the system has stabilized, record data in the Daily Log Sheet. It may take several days for the permeate flow rate to stabilize.
5. After starting up the system, the steady green **RUN** LED will light. During the 5 second delay before the pump starts, the digital display will show "---". If the concentrate and recycle flows are set correctly, the system will operate automatically, even after a power failure.
6. On Deluxe models, once permeate is present at the TDS sensor, the digital TDS display will show the temperature corrected TDS based on the conductivity of the water. If the TDS is above 999 ppm, the digital display will show "Λ Λ Λ". The TDS of the permeate water can also be measured manually.
7. After the system has been running, the permeate water tank (supplied separately) will fill. When the water level rises and closes the normally open full tank sensor for 5 seconds, the **FULL TANK** LED will light Green and the digital display will show "FUL".
8. Once the tank is full, the steady yellow **FLUSH** LED will light, the inlet solenoids will remain open and the pump will run for 5 minutes while the concentrate bypass solenoid will open to flush concentrate to drain for five minutes. The digital display on Deluxe models will show "FLS" then "---". After five minutes, the inlet solenoid will close, the pump will turn off and the concentrate bypass solenoid will close.
9. After the water level has dropped in the tank and the top water level switch of the tank opens, the green **FULL TANK** LED light will flash for 15 minutes. After 15 minutes the **FULL TANK** light will turn off and the system will start up again to fill the tank.
10. If the pretreat system goes into bypass or shuts off for 2 seconds, the **PRE-TREAT** lock-out will be steady green, the inlet solenoid will close and the pump will shut off so untreated water does not run through the RO system. The digital display will show "PL" then "---".
11. If the system experiences low pressure for more than 2 seconds, the pump will shut off, the inlet solenoid will close, the red **LOW PRESSURE** LED will flash and the digital display will show "LP" then "---". After 30 seconds, the system will attempt to restart. If the pressure is still too low, the shutoff and restart cycle will repeat again at 5 minutes and then at 30 minutes. If the pressure is still too low after 30 minutes, the system will shut down and the **RUN** button will have to be pressed twice to clear the fault. Before restarting the system, the water supply to the system including pretreatment, valves and the prefilter should be checked for adequate pressure at the required water flow. If the pressure fault clears by running for more than 10 seconds, the retry function is reset and will function normally

System Requirements

The HighPure RO System will run effectively only when the feed water meets certain requirements. The specifications table details the feed water for each model of HighPure RO System.

When the RO system is installed and made operational it is important to fill in the *Installation and Start-up Checklist* at the front of this manual. If the RO system is not performing properly review the check list and be certain the feed water is within specifications.

Troubleshooting



CAUTION

Hazardous voltages are present when power is applied to the controller. Pressing the Power key DOES NOT remove these voltages. The power must be disconnected from the power source. When connecting or disconnecting any wiring to the unit, be sure the power is turned off at disconnect or breaker. Lock out/Tag out rules may apply. Note that if fuse F1 or F2 is blown, none of the outputs will operate. If fuse F3 is blown, the Controller will be inoperative. Refer to Figure 2 for the location of components.

This troubleshooting guide can assist in identifying common operating problems that may be experienced with the machine. The operator can easily correct many of these problems. For those that persist or are not understood, contact the Pentair Technical Support Center. Have the following Information available when calling the Customer Support Center:

1. Installation and start-up checklist
2. Detailed description of problem
3. Operation Log

Symptom	Possible Causes	Remedies
Low permeate flow rate	Low membrane pressure.	See possible causes for low operating pressure.
	Dirty or fouled membrane elements.	Flush and clean the membrane elements.
	Operating on cold water see temperature correction table.	Install a hot/cold feed water tempering valve if more permeate flow is needed. Operate at higher feed water temperature up to 72 –77°F (22–25°C).
	Membrane elements installed backward or damaged concentrate seal.	Install membrane elements in the direction of fluid flow. Flush and clean the machine immediately.
	Flow meter inaccurate.	Check the flow rate manually with a stopwatch and calibrated container.
Machine not operating.	No power to machine or display.	Check the controller internal fuses and check circuit breakers. Measure the voltage. Check electrical outlet. Defective board in controller.
	External contacts have shut machine down.	Check for closed contacts - tank full, pre-treat lockout and pressure fault.
	Thermal overload in motor has tripped.	Allow the machine to cool. Check the feed water supply and/or amp draw to the motor.
	Motor and/or pump not operating properly.	See pump instructions. Contact Pentair for possible repair or replacement. Check Fuses F1 and F2.
	Low pressure condition has turned OFF machine. The low pressure LED will flash.	Check for minimum inlet pressure and push power button twice. See low operating pressure.
	Tank level switch has shut off the machine.	If tank is full LED will be on - wait for tank to empty. If LED is flashing the control is in a delayed restart for up to 15 minutes
	Fuse F3 bad.	The water quality display will not be lit. Check or replace fuse F3 located below the transformer.
	No power at terminals L1 and L2.	Use VOM meter to check for power.
	Control board defective.	Check for power at terminals L1 and L2. If power is present control board may need replacing.

Troubleshooting

Symptom	Possible Causes	Remedies
Low operating pressure.	Clogged prefilter cartridge.	Replace prefilter cartridge.
	Insufficient feed water flow/pressure.	Increase the feed pressure. Open the feed water valve. Check for restrictions and proper pipe sizes.
	High flow rates.	Close the concentrate valve. Check the permeate and concentrate flow rates. Adjust if necessary. Excessive permeate flow may indicate a damaged O-ring.
	Dirty or fouled membrane elements.	Flush and clean the membrane elements.
	Solenoid valve not opening.	Clean or replace the solenoid valve.
	Insufficient electrical power.	Check the fuses or circuit breakers: measure the voltage.
	Pump not operating correctly.	See pump instructions.
High TDS reading.	Incoming water pressure low.	Increase water pressure to prefilter. Prefilter may need replacing.
	Water temperature high.	Consult water temperature tables. Lower incoming water temperature.
	High recycle.	Adjust recycle flow meter.
	TDS probe not calibrated.	Calibrate probe.
	Recovery too high with low concentrate flow.	Lower the recovery by increasing concentrate flow.
	Pinched or damaged O-ring on membrane	Replace O-ring and check O-ring sealing surfaces.
	Damaged membrane.	Clean or replace membrane. Check chlorine pre-treatment.
	Change in incoming water quality.	Open the concentrate valve and flush. Test the feed water for pH, hardness, TDS, silica and iron content. A feed water analysis should be performed.
Incorrect TDS reading.	Sensor not wired correctly.	Check wiring and correct.
	Sensor not installed correctly.	Check installation and reinstall.
	Not calibrated correctly.	Recalibrate.
	Controller board bad.	Remove green and white wires from sensor to board. Is TDS reading 0? If no replace controller board. If yes, see "sensor bad" and reconnect wires.
	Sensor bad.	Remove sensor from piping and dry off. Display should show 0. If no, replace sensor. If yes, short the pins of the sensor. Display should show "Λ Λ Λ". If no replace board.
Low concentrate flow rate, normal or higher than normal pressure.	Concentrate valve plugged.	Remove the concentrate valve and /or disassemble the piping. Clean the valve.
	Concentrate out line restricted.	Examine the concentrate line for obstructions or kinks, repair or replace the tubing.
	Flow meter inaccurate.	Check the flow rate manually with a stopwatch and calibrated container.
	Dirty concentrate valve.	Disassemble and clean the piping to the valve.
	Improper pump operation.	Rebuild or replace.
	Extremely fouled membranes.	Clean or replace.
	Recycle flow too high.	Adjust down.

Troubleshooting

Symptom	Possible Causes	Remedies
Water flowing when machine is turned OFF.	Inlet Solenoid valve not closing or seating properly.	Clean or replace the valve. Water must not pass through the inlet when the machine is OFF.
	Faulty permeate check valve.	Verify proper air gap at drain replace the permeate check valve.
High operating pressure.	Recycle or concentrate valve closed, plugged or damaged.	Disassemble the piping to the recycle valve and remove foreign particles. Check the concentrate valve.
	Inaccurate pressure gauge.	Replace or calibrate the gauge as required.
	Restricted flow after pump outlet.	Check for blockage of the concentrate flow at the inlets and outlets of the membrane element housings.
	Plugged/fouled membranes.	Clean or replace membranes as needed.
Inlet valve not operating.	Controller board inactive.	Is controller turned on? Are any shut-down conditions active? If no is the inlet LED lit? If no the controller board may be bad. If yes check fuses F1 and F2. Check inlet terminals for power. If no replace controller board. If yes check valve and valve wiring.
RO pump not operating.	Controller board inactive.	Is controller turned on? Are any shut-down conditions active? If no is the inlet LED lit? If no the controller board may be bad. If yes check fuses F1 and F2. If bad replace fuse(s). If ok, check RO pump terminals for power. If no replace controller board. If yes check the pump motor and wiring.

Troubleshooting and rebuilding pump. See Berkeley Pump Owners manual provided with system or go to:
<http://www.berkeleypumps.com/pdf/BE327.PDF>




For customer support contact:

Pentair Water Commercial and Industrial Purity Solutions Technical and Application Support

Phone: 877.372.8265

E-mail: Tech.SupportCIPS@Pentair.com

General

	WARNING To prevent electrical hazards, disconnect power supply to the RO system before servicing the unit.
	WARNING Water supply should come from a reliable potable source that will comply with feed water requirements. Failure to comply will result in improper operation, damage to the equipment and will void the warranty.
	CAUTION Proper pre-treatment must be maintained. Regular carbon changes and proper maintenance of pre-treatment salts and chemicals is required. Do not install a chemical feed in the permeate line as this could damage the membranes when unit shuts down. To add a chemical to the permeate water, feed the chemical directly into the permeate storage tank. If chemical feed is connected directly to the feed water then a flow sensor must be used.

Maintenance and Servicing

The most trouble free systems are those that are not turned off and run continuously. A well kept Operating Log must be maintained and acted upon as soon as needed to avoid complications.

Replacing Inlet Cartridge Filters

The pressure drop across the inlet cartridge filter will increase with time as the volume of filtered water increases, and the load of solids removed clogs the filter. This will clearly be seen in the Operating Log. The inlet cartridge filter needs to be replaced when the pressure drop across the filter doubles or exceeds 6 psi higher than the Δ pressure at start-up, whichever is lower.


Failure to replace the cartridge on time may cause the cartridge to fail and allow suspended solids to pass into the RO system and void the warranty. During normal operation the pressure drop will continue to increase lowering the pressure at the pump inlet and lowering the system's capabilities.

To change the cartridge, you will need to shut down the system and the feed water supply. Replace cartridge, clean and sanitize the housing if needed. Place new clean cartridge into the sump. Lubricate the O-ring with glycerin and replace in the groove of sump below threads. Screw sump to filter head. Purge out air before start-up.

Record in the Operating Log the cartridge replacement on the day it happened, together with all the other operating data.

TDS Calibration

The TDS calibration of the TDS monitor should rarely have to be adjusted. To adjust the calibration screw shown as CAL on the circuit board inside the control box in Figure 2; measure the incoming water supply with a meter calibrated to a known standard. Using a small non-conducting plastic bladed screwdriver, adjust the CAL screw to get the correct reading on the display.

	WARNING Never use a metal screwdriver to adjust the CAL screw. Remove any jewelry that could contact any electrical components in the control box. Any contact with the electrical circuit on the board could cause death or severe injury or damage to the controller.
---	---

Rebuilding Pump

See Berkeley Pump Owners manual provided with system or go to: <http://www.berkeleypumps.com/pdf/BE327.PDF>

Maintenance

Cleaning the Membranes

The following membrane cleaning summary is taken from several papers by Hydranautics.

Common foulants affecting the performance of the supplied Hydranautics' ESPA1 Composite Polyamide Reverse Osmosis (RO) membrane elements and the removal of these foulants. The information applies to 4-inch diameter RO membrane elements.

NOTE: It is recommended that all RO membrane cleaning operations should be closely coordinated with Hydranautics. Hydranautics field service personnel are available to be on site for cleaning assistance. Please contact Hydranautics for current charges for this service.

NOTE: The use of cationic surfactant should be avoided in cleaning solutions, since irreversible fouling of the membrane elements may occur.

If additional information is needed, please contact the Technical Services Department at:

HYDRANAUTICS
401 Jones Rd.
Oceanside, CA 92058
Tel# (760) 901-2500
Fax# (760) 901-2664
e-mail: info@hydranautics.com
Internet: www.membranes.com

RO Membrane Fouling and Cleaning

During normal operation over a period of time, RO membranes are subject to fouling by suspended or sparingly soluble materials that may be present in the feed water. Common examples of foulants are:

- Calcium carbonate scale
- Sulfate scale of calcium, barium or strontium
- Metal oxides (iron, manganese, copper, nickel, aluminum, etc.)
- Polymerized silica scale
- Inorganic colloidal deposits
- Mixed inorganic/organic colloidal deposits
- NOM organic material (Natural Organic Matter)
- Man-made organic material (e.g. antiscalant/dispersants, cationic polyelectrolytes)
- Biological (bacterial bioslime, algae, mold, or fungi)

The nature and rapidity of fouling depends on a number of factors, such as the quality of the feed water and the system recovery rate. Typically, fouling is progressive, and if not controlled early, will impair the RO membrane element performance in a relatively short time. Cleaning should occur when the RO shows evidence of fouling, just prior to a long-term shutdown, or as a matter of scheduled routine maintenance. The elements shall be maintained in a clean or "nearly clean" condition to prevent excessive fouling by the foulants listed above. Some fouling is allowed as long as:

- normalized permeate flow decrease is less than 10%
- normalized permeate quality decrease is less than 10%
- normalized pressure drop, as measured between the feed and concentrate headers, increase is less than 15%.

Organic fouling of the membranes can cause an increase in the feed pressure and an improved permeate water quality and reduce permeate flow. For more information contact your membrane cleaner supplier.

**WARNING**

Failure to clean the membranes on time may cause irreversible fouling of the membranes requiring their early replacement.

Indicators can be seen in the Operation Log. All of these problems develop slowly and are easy to see in the log as the problem progresses. A close monitoring of the Operation Log will reveal the problem on time and you won't need to find the normalized flows to proceed to clean the membranes. Membranes should be kept as clean as possible at all times.

Given that all other variables are held constant, Table 2 gives general trends that can be followed in the daily logs.

Table 2: Operation Trends

If:	Increases or Decreases:	Then:	Increases or Decreases:	And Permeate Flow or TDS	Increases or Decreases:
Temp	↑	Rejection	↓	Permeate	↑
Temp	↓	Rejection	↑	Permeate	↓
Pressure	↑	Rejection	↑	Permeate	↑
Pressure	↓	Rejection	↓	Permeate	↓
Recovery	↑	Potential Fouling	↑	TDS	↑
Recovery	↓	Potential Fouling	↓	TDS	↓

Provide feed water quality and Operating Log data to the system designer or any other reputable service to seek advice on identifying the cause of the fouling/scaling and what will be the most acceptable cleaning procedure.

Cleaning should be carried out before these values are exceeded to maintain the elements in a clean or “nearly clean” condition. Effective cleaning is evidenced by the return of the normalized parameters to their initial Start-up value. In the event you do not normalize your operating data, the above values still apply if you do not have major changes in critical operating parameters. The operating parameters that have to stay constant are permeate flow, permeate back-pressure, recovery, temperature, and feed TDS. If these operating parameters fluctuate, then it is highly recommended that you normalize the data to determine if fouling is occurring or if the RO is actually operating normally based on the change in a critical operating parameter. Hydranautics offers a free normalization software program called ROData, which can be downloaded from their web site at www.membranes.com.

Monitoring overall system performance on a regular basis is an essential step in recognizing when membrane elements are becoming fouled. Performance is affected progressively and in varying degrees, depending on the nature of the foulants. Table 1 “RO Troubleshooting Matrix” provides a summary of the expected effects that common foulants have on performance.

RO cleaning frequency due to fouling will vary by site. A rough rule of thumb as to an acceptable cleaning frequency is once every 3 to 12 months. If you have to clean more than once a month, you should be able to justify further capital expenditures for improved RO pretreatment or a re-design of the RO operation. If the cleaning frequency is every one to three months, you may want to focus on improving the operation of your existing equipment but further capital expenditure may be harder to justify.

It is important to clean the membranes when they are only lightly fouled, not heavily fouled. Heavy fouling can impair the effectiveness of the cleaning chemical by impeding the penetration of the chemical deep into the foulant and in the flushing of the foulant out of the elements. If normalized membrane performance drops 30 to 50%, it may be impossible to fully restore the performance back to baseline conditions.

Maintenance

When inorganic coagulants are used in the pretreatment process, there can often be incomplete reaction of the inorganic salt and thus insufficient formation of a filterable floc. The user should ensure that excessive amounts of inorganic coagulant are not fed to the RO system. Excessive amounts of coagulant can be measured by using SDI filter equipment. In the case of iron, the iron on the SDI filter pad should typically be 3 µg/pad and never above 5 µg/pad.

In addition to the use of turbidity and SDI, particle counters are also very effective to accurately measure the suitability of the feedwater for NF/RO elements. The measure of particles greater than 2 microns in size should be < 100 particles per milliliter.

What you clean for can vary site by site depending on the foulant. Complicating the situation frequently is that more than one foulant can be present, which explains why cleanings frequently require a low pH and high pH cleaning regiment.

NOTE: The membrane elements shall not be exposed to feed water containing oil, grease, oxidizers or other foreign matter which proves to chemically or physically damage the integrity of the membrane.

Table 3: RO Troubleshooting Matrix

Pressure Drop is defined as the Feed pressure minus the Concentrate pressure.

This table was created by Hydranautics, a Nitto Denko Company.

Possible Cause	Possible Location	Pressure Drop	Feed Pressure	Salt Passage
Metal Oxide Fouling (e.g/ Fe, Mn, Cu, Ni, Zn)	1 st stage lead elements	Rapid increase	Rapid increase	Rapid increase
Colloidal Fouling (organic and/or inorganic complexes)	1 st stage lead elements	Gradual increase	Gradual increase	Slight increase
Mineral Scaling (e.g. Ca, Mg, Ba, Sr)	Last stage tail elements	Moderate increase	Slight increase	Marked increase
Polymerized Silica	Last stage tail elements	Normal to increased	Increased	Normal to increased
Biological Fouling	Any stage, usually lead elements	Marked increase	Marked increase	Normal to increased
Organic Fouling (dissolved Natural Organic Matter, NOM)	All stages	Gradual increase	Increased	Decreased
Antiscalant Fouling	2 nd stage most severe	Normal to increased	Increased	Normal to increased
Oxidant damage (e.g. Cl ₂ , ozone, KMnO ₄)	1 st stage most severe	Normal to decreased	Decreased	Increased
Hydrolysis damage (out of range pH)	All stages	Normal to decreased	Decreased	Increased
Abrasion damage (carbon fines, etc)	1 st stage most severe	Normal to decreased	Decreased	Increased
O-ring leaks (at interconnectors or adapters)	Random, typically at feed adapter	Normal to decreased	Normal to decreased	Increased
Glue line leaks (due to permeate backpressure in service or standby)	1 st stage most severe	Normal to decreased	Normal to decreased	Increased
Glue line leaks (due to closed permeate valve while cleaning or flushing)	Tail element of a stage	Increased (based on prior fouling and high delta P)	Increased (based on prior fouling and high delta P)	Increased

Types of Foulants

Calcium Carbonate Scale: Calcium carbonate is a mineral scale and may be deposited from almost any feedwater if there is a failure in the antiscalant/dispersant addition system or in the acid injection pH control system that results in a high feedwater pH. An early detection of the resulting calcium carbonate scaling is absolutely essential to prevent the damage that crystals can cause on the active membrane layers. Calcium carbonate scale that has been detected early can be removed by lowering the feedwater pH to between 3.0 and 5.0 for one or two hours. Longer resident accumulations of calcium carbonate scale can be removed by a low pH cleaning with a citric acid solution.

Calcium, Barium & Strontium Sulfate Scale: Sulfate scale is a much “harder” mineral scale than calcium carbonate and is harder to remove. Sulfate scale may be deposited if there is a failure in the antiscalant/dispersant feed system or if there is an over feed of sulfuric acid in pH adjustment. Early detection of the resulting sulfate scaling is absolutely essential to prevent the damage that crystals can cause on the active membrane layers. Barium and strontium sulfate scales are particularly difficult to remove as they are insoluble in almost all cleaning solutions, so special care should be taken to prevent their formation.

Calcium Phosphate Scale: This scale is particularly common in municipal waste waters and polluted water supplies which may contain high levels of phosphate. This scale can generally be removed with acidic pH cleaners.

Metal Oxide/Hydroxide Foulants: Typical metal oxide and metal hydroxide foulants are iron, zinc, manganese, copper, aluminum, etc. They can be the result of corrosion products from unlined pipes and tanks, or result from the oxidation of the soluble metal ion with air, chlorine, ozone, potassium permanganate, or they can be the result of a pretreatment filter system upset that utilizes iron or aluminum based coagulant aids.

Polymerized Silica Coating: A silica gel coating resulting from the super-saturation and polymerization of soluble silica can be very difficult to remove. It should be noted that this type of silica fouling is different from silica-based colloidal foulants, which may be associated with either metal hydroxides or organic matter. Silica scale can be very difficult to remove by traditional chemical cleaning methods. Contact Hydranautics technical department if the traditional methods are unsuccessful. Harsher cleaning chemicals, like ammonium bifluoride, have been used successfully at some sites but are considered rather hazardous to handle and can damage equipment.

Colloidal Foulants: Colloids are inorganic or mixed inorganic/organic based particles that are suspended in water and will not settle out due to gravity. Colloidal matter typically contains one or more of the following major components: iron, aluminum, silica, sulfur, or organic matter.

Dissolved NOM Organic Foulants: The sources of dissolved NOM (Natural Organic Matter) foulants are typically derived from the decomposition of vegetative material into surface waters or shallow wells. The chemistry of organic foulants is very complex, with the major organic components being either humic acid or fulvic acid. Dissolved NOMs can quickly foul RO membranes by being absorbed onto the membrane surface. Once absorption has occurred, then a slower fouling process of gel or cake formation starts. It should be noted that the mechanism of fouling with dissolved NOM should not be confused with the mechanism of fouling created by NOM organic material that is bound up with colloidal particles.

Microbiological Deposits: Organic-based deposits resulting from bacterial slimes, fungi, molds, etc. can be difficult to remove, particularly if the feed path is plugged. Plugging of the feed path makes it difficult to introduce and distribute the cleaning solutions. To inhibit additional growth, it is important to clean and sanitize not only the RO system, but also the pretreatment, piping, dead-legs, etc. The membranes, once chemically cleaned, will require the use of an approved biocide and an extended exposure requirement to be effective.

Maintenance

Selection and Use of Cleaning Chemicals

There are a number of factors involved in the selection of a suitable cleaning chemical (or chemicals) and proper cleaning protocol. The first time you have to perform a cleaning, it is recommended to contact the manufacturer of the equipment, the RO element manufacturer, or a RO specialty chemical and service supplier. Once the suspected foulant(s) are identified, one or more cleaning chemicals will be recommended. These cleaning chemical(s) can be generic or can be private-labeled proprietary chemicals. Typically, the generic chemicals can be of technical grades and are available from local chemical supply companies. The proprietary RO cleaning chemicals can be more expensive, but may be easier to use and you cannot rule out the advantage of the intellectual knowledge supplied by these companies. Some independent RO service companies can determine the proper chemicals and cleaning protocol for your situation by testing at their facility a fouled element pulled from your system.

It is not unusual to use a number of different cleaning chemicals in a specific sequence to achieve the optimum cleaning. Typically, a high pH cleaning is used first to remove foulants like oil or biological matter, followed by a low pH cleaning to remove foulants like mineral scale or metal oxides/hydroxides fouling. There are times that order of high and low pH cleaning solutions is reversed or one solution only is required to clean the membranes. Some cleaning solutions have detergents added to aid in the removal of heavy biological and organic debris, while others have a chelating agent like EDTA added to aid in the removal of colloidal material, organic and biological material, and sulfate scale. An important thing to remember is that the improper selection of a cleaning chemical, or the sequence of chemical introduction, can make the foulant worse.

It is recommended that the membrane system operator thoroughly investigate the signs of fouling before they select a cleaning chemical and a cleaning protocol. Some forms of fouling (iron deposits and scaling commonly associated with well waters) may require only a simple low pH cleaning. However, for most complex fouling phenomena, the following sequence is recommended:

1. Flushing with permeate with addition of non oxidizing biocide Isothiazolin (Kathon) or Sodium Bisulfite or similar type) at the end of the flushing.
2. High pH CIP – Temperature versus pH as per recommendations
3. Flushing with permeate until pH on the brine side is below pH 8.5
4. Low pH CIP
5. Acid flushing with permeate and non oxidizing biocide (Isothiazolin [Kathon] or Sodium Bisulfite or similar type)

General Precautions in Cleaning Chemical Selection and Usage

- If you are using a proprietary chemical, make sure the chemical has been qualified for use with your membrane by the chemical supplier. The chemical supplier's instructions should not be in conflict with membrane suppliers recommended cleaning parameters.
- If you are using generic chemicals, make sure the chemical has been qualified for use with your membrane.
- Use the least harshest cleaning regiment to get the job done. This includes the cleaning parameters of pH, temperature, and contact time. This will optimize the useful life of the membrane.
- Clean at the recommended target temperatures to optimize cleaning efficiency and membrane life.
- Use the minimal amount of chemical contact time to optimize membrane life.
- Be prudent in the adjustment of pH at the low and high pH range to extend the useful life of the membrane. A "gentle" pH range is 4 to 10, while the harshest is 2 to 12.
- Oil and biologically-fouled membranes should not use a low pH clean-up first as the oil and biological matter will congeal.
- Cleaning and flushing flows should be in the same direction as the normal feed flow to avoid potential telescoping and element damage.
- When cleaning a multi-stage RO, the most effective cleaning is one stage at a time so cleaning flow velocities can be optimized and foulants from upstream stages don't have to pass through downstream stages.
- Flushing out detergents with higher pH permeate can reduce foaming problems.
- Verify that proper disposal requirements for the cleaning solution are followed.

- If your system has been fouled biologically, you may want to consider the extra step of introducing a sanitizing biocide chemical before and after a successful cleaning. Biocides can be introduced before and immediately after cleaning, periodically (e.g. once a week), or continuously during service. You must be sure that the biocide is compatible with the membrane, does not create any health risks, is effective in controlling biological activity, and is not cost prohibitive.
- For safety reasons, make sure all hoses and piping can handle the temperatures, pressures and pH's encountered during a cleaning.
- For safety reasons, always add chemicals slowly to an agitated batch of make-up water.
- For safety reason, always wear safety glasses and protective gear when working with chemicals.
- For safety reasons, don't mix acids with caustics. Thoroughly rinse the 1st cleaning solution from the RO system before introducing the next solution.

Description of Cleaning Solutions

NOTE: The notation (w) denotes that the diluted chemical solution strength is based on the actual weight of the 100% pure chemical or active ingredient.

Solution 1: This is a low pH cleaning solution of 2.0% (w) citric acid ($C_6H_8O_7$). It is useful in removing inorganic scale (e.g. calcium carbonate, calcium sulfate, barium sulfate, strontium sulfate) and metal oxides/hydroxides (e.g. iron, manganese, nickel, copper, zinc), and inorganic-based colloidal material. Note: Citric acid is available as a powder.

Solution 2: This is a high pH cleaning solution (target pH of 10.0) of 2.0% (w) of STPP (sodium tripolyphosphate) ($Na_5P_3O_{10}$) and 0.8% (w) of Na-EDTA (sodium salt of ethylenediaminetetraacetic acid). It is specifically recommended for removing calcium sulfate scale and light to moderate levels of organic foulants of natural origin. STPP functions as an inorganic-based chelating agent and detergent. Na-EDTA is an organic-based chelating cleaning agent that aids in the sequestering and removal of divalent and trivalent cations and metal ions. STPP and Na-EDTA are available as powders.

Solution 3: This is a high pH cleaning solution (target pH of 10.0) of 2.0% (w) of STPP (sodium tripolyphosphate) ($Na_5P_3O_{10}$) and 0.025% (w) Na-DDBS [$C_{12}H_{25}SO_3Na$] (sodium salt of dodecylbenzene sulfonate). It is specifically recommended for removing heavier levels of organic foulants of natural origin. STPP functions as an inorganic-based chelating agent and detergent. Na-DDBS functions as an anionic detergent.

Solution 4: This is a low pH cleaning solution (target pH of 2.5) of 0.5% (w) of HCL (hydrochloric) acid. It is useful in removing inorganic scale (e.g. calcium carbonate, calcium sulfate, barium sulfate, strontium sulfate and metal oxides/hydroxides (e.g. iron, manganese, nickel, copper, zinc) and inorganic-based colloidal material. This cleaning solution is considered to be harsher than Solution 1. HCL acid, a strong mineral acid, is also known as muriatic acid. HCL acid is available in a number of concentrations: (18° Baume = 27.9%), (20° Baume = 31.4%), (22° Baume = 36.0%).

Solution 5: This is a lower pH cleaning solution (natural pH is between pH 4 and 6. No pH adjustment is required) 1.0% (w) of $Na_2S_2O_4$ (sodium hydrosulfite). It is useful in the removal of metal oxides and hydroxides (especially iron fouling), and to a lesser extent calcium sulfate, barium sulfate and strontium sulfate. Sodium hydrosulfite is strong reducing agent and is also known as sodium dithionite. The solution will have a very strong odor so proper ventilation is required. Sodium hydrosulfite is available as a powder.

Solution 6: This is a high pH cleaning solution (target pH of 11.5) of 0.1% (w) of NaOH (sodium hydroxide) and 0.03% (w) of SDS (sodium dodecylsulfate). It is useful in the removal of organic foulants of natural origin, colloidal foulants of mixed organic/inorganic origin, and biological material (fungi, mold, slimes and biofilm). SDS is a detergent that is an anionic surfactant that will cause some foaming. This is considered to be a harsh cleaning regiment.

Solution 7: This is a high pH cleaning solution (target pH of 11.5) of 0.1% (w) of NaOH (sodium hydroxide). It is useful in the removal of polymerized silica. This is considered to be a harsh cleaning regiment.

IMPORTANT: It is recommended that the MSDS of the cleaning chemicals be procured from the chemical supplier and that all safety precautions be utilized in the handling and storage of all chemicals.

Maintenance

Selecting a Cleaning Solution

Table 4 lists the recommended generic chemical solutions for cleaning an RO membrane element based on the foulant to be removed.

IMPORTANT: It is recommended that the MSDS of the cleaning chemicals be procured from the chemical supplier and that all safety precautions be utilized in the handling and storage of all chemicals.

Table 4: Hydranautics Recommended Chemical Cleaning Solutions

Foulant	Gentle Cleaning Solution	Harsher Cleaning Solution
Calcium carbonate scale	1	4
Calcium, barium or strontium sulfate scale	2	4
Metal oxides/hydroxides (Fe, Mn, Zn, Cu, Al)	1	5
Inorganic colloidal foulants	1	4
Mixed Inorganic/organic colloidal foulants	2	6
Polymerized silica coating	None	7
Biological matter	2 or 3	6
NOM organic matter (naturally occurring)	2 or 3	6

Table 5, Hydranautics Recipes for Cleaning Solutions, offers instructions on the volumes of bulk chemical to be added to 100 U.S. gallons (379 liters) of make-up water. Prepare the solutions by proportioning the amount of chemicals to the amount of make-up water to be used. Make-up water quality should be of RO permeate or deionized (DI) quality, and be free of chlorine and hardness. Before forwarding the cleaning solution to the membranes, it is important to thoroughly mix it, adjust the pH according to the target pH, and stabilize the temperature at the target temperature. Unless otherwise instructed, the cleaning design parameters are based on a chemical recirculation flow period of one hour and an optional chemical soak period of one hour.

Table 5: Hydranautics Recipes for Cleaning Solutions

The quantities listed below are to be added to 100 U.S. gallons (379 liters) of dilution water.

Cleaning Solution	Bulk Ingredients	Quantity	Target pH Adjustment	Target Temp.
1	Citric acid (as 100% powder)	17.0 pounds (7.7 kg)	No pH adjustment is required.	104°F (40°C)
2	STPP (sodium tripolyphosphate) (as 100% powder)	17.0 pounds (7.7 kg)	Adjust to pH 10.0 with sulfuric or hydrochloric acid.	104°F (40°C)
	Na-EDTA (Versene 220 or equal) (as 100% powder)	7.0 pounds (3.18 kg)		
3	STPP (sodium tripolyphosphate) (as 100% powder)	17.0 pounds (7.7 kg)	Adjust down to pH 10.0 with sulfuric or hydrochloric acid.	104°F (40°C)
	Na-DDBS (Na-dodecylbenzene sulfonate)	0.21 pounds (0.1 kg)		
4	HCl acid (hydrochloric acid) (as 22° Baume or 36% HCL)	0.47 gallons (1.78 liters)	Slowly adjust pH down to 2.5 with HCL acid. Adjust pH up with sodium hydroxide.	95°F (35°C)
5	Sodium hydrosulfite (as 100% powder)	8.5 pounds (3.86 kg)	No pH adjustment is required.	95°F (35°C)
6	NaOH (sodium hydroxide) (as 100% powder) (or as 50% liquid)	0.83 pounds (0.38 kg) 0.13 gallons (0.49 liters)	Slowly adjust pH up to 11.5 with sodium hydroxide. Adjust pH down to 11.5 by adding HCL acid.	86°F (30°C)
	SDS (sodium dodecylsulfate)	0.25 pounds (0.11 kg)		
7	NaOH (sodium hydroxide) (as 100% powder) (or as 50% liquid)	0.83 pounds (0.38 kg) 0.13 gallons (0.49 liters)	Slowly adjust pH up to 11.5 with sodium hydroxide. Adjust pH down to 11.5 by adding HCL acid.	86°F (30°C)

Table 6, Hydranautics pH and Temperature Limits for Cleaning, highlights the maximum pH and temperature limits for specific membranes, after which irreparable membrane damage can occur. A suggested minimum temperature limit is 70 F (21 C), but cleaning effectiveness and the solubility of the cleaning chemical is significantly improved at higher temperatures.

Table 6: Hydranautics pH and Temperature Limits for Cleaning

See Table 5 for target pH and temperatures

Membrane	45°C (113°F)	40°C (105°F)	30°C (86°F)
ESPA	2-10	2-11.5	2-12

NOTE: The above cleaning parameters denote the maximum temperature limits for a corresponding range of pH. Cleaning operations performed at the extremes may result in a more effective cleaning, but can shorten the useful life of the membrane due to hydrolysis. To optimize the useful life of a membrane, it is recommended to use the weakest cleaning solutions and minimize the contact time whenever possible.

Table 7: Cleaning and Flushing Flow Rates per RO Pressure Tube

Pressures are not to exceed 60 psi (4 bar) at inlet to tubes.

Element Diameter	GPM	LPM
4-inches	6 to 10	23 to 38

Maintenance

Table 8: Cleaning Solution Volume Requirement per RO Element

(these volumes do not include volumes required for piping, filters, etc)

(these volumes do not include initial 20% of volume dumped to drain)

Element Size	Normal Fouling (Gallons)	Heavy Fouling (Gallons)	Normal Fouling (Liters)	Heavy Fouling (Liters)
4 x 40 inches	2.5	5	9.5	19

RO Cleaning Skid

The successful cleaning of an RO system on-site requires a well designed RO cleaning skid. Normally this skid is not hard piped to the RO skid and uses temporary hosing for connections. It is recommended to clean a multi-stage RO one stage at a time to optimize cross-flow cleaning velocity. The source water for chemical solution make-up and rinsing should be clean RO permeate or DI water and be free of hardness, transition metals (e.g. iron), and chlorine. Components must be corrosion proof. Major cleaning system components are:




Figure 7 CIP Connections

- **RO Cleaning Tank:** This tank needs to be sized properly to accommodate the displacement of water in the hose, piping, and RO elements. The tank should be designed to allow 100 % drainage, easy access for chemical introduction and mixing, a recirculation line from the RO Cleaning Pump, proper venting, overflow, and a return line located near the bottom to minimize foam formation when using a surfactant.
- **RO Cleaning Pump:** This pump needs to be sized to develop the proper cross-flow velocity to scrub the membrane clean. The maximum recommended pressure is 60 psi (4 bar) at the inlet to the pressure vessels to minimize the production of permeate during cleaning and reduce the convective redeposition of foulant back on to the membrane surface. The table below denotes the flow rate ranges for each pressure tube.
- **RO Cleaning Cartridge Filter:** Normally 5 to 10-micron and is designed to remove foulants that have been displaced from the cleaning process.
- **RO Tank Heater or Cooler:** The maximum design temperature for cleaning is 113° F (45° C). It should be noted that heat is generated and imparted by the RO Cleaning Pump during recirculation.
- **RO Tank Mixer:** This is recommended to get optimal mixing of chemical, though some designers rely solely on the slow introduction of chemical while maintaining a recirculation through the RO Cleaning Pump back to the tank.
- **Instrumentation:** Cleaning system instrumentation should be included to monitor flow, temperature, pressure, and tank level.
- **Sample Points:** Sample valves should be located to allow pH and TDS measurements off the RO Cleaning Pump discharge and the concentrate side recirculation return line.
- **Permeate Return Line:** A small amount of the cleaning solution can permeate through the membranes and so a permeate-side return line back to the RO Cleaning Tank is required.

IMPORTANT: The permeate line and any permeate valves must always be open to atmospheric pressure during the cleaning and flushing steps or damage to RO elements can occur. If the permeate line is closed, the permeate pressure can build up and become higher than the feed-side pressure of the tail elements. This can result in excessive permeate back-pressure which can damage the membrane glue lines in the tail elements.

RO Membrane Element Cleaning and Flushing Procedures

The RO membrane elements can be cleaned in place in the pressure tubes by recirculating the cleaning solution across the high-pressure side of the membrane at low pressure and relatively high flow. A cleaning unit is needed to do this. RO cleaning procedures may vary dependent on the situation. The time required to clean a stage can take from 4 to 8 hours.

A general procedure for cleaning the RO membrane elements is as follows:

1. Perform a low pressure flush at 60 psi (4.2 Kg/cm²) or less of the pressure tubes by pumping clean water from the cleaning tank (or equivalent source) through the pressure tubes to drain for several minutes. Flush water should be clean water of RO permeate or DI quality and be free of hardness, transition metals, and chlorine.
2. Mix a fresh batch of the selected cleaning solution in the cleaning tank. The dilution water should be clean water of RO permeate or DI quality and be free of hardness, transition metals, and chlorine. The temperature and pH should be adjusted to their target levels.
3. Circulate the cleaning solution through the pressure tubes for approximately one hour or the desired period of time. At the start, send the displaced water to drain so you don't dilute the cleaning chemical and then divert up to 20% of the most highly fouled cleaning solution to drain before returning the cleaning solution back to the RO Cleaning Tank. For the first 5 minutes, slowly throttle the flow rate to 1/3 of the maximum design flow rate. This is to minimize the potential plugging of the feed path with a large amount of dislodged foulant. For the second 5 minutes, increase the flow rate to 2/3 of the maximum design flow rate, and then increase the flow rate to the maximum design flow rate. If required, readjust the pH back to the target when it changes more than 0.5 pH units.
4. An optional soak and recirculation sequence can be used, if required. The soak time can be from 1 to 8 hours depending on the manufacturer's recommendations. Caution should be used to maintain the proper temperature and pH. Also note that this does increase the chemical exposure time of the membrane.
5. Upon completion of the chemical cleaning steps, a low pressure Cleaning Rinse with clean water (RO permeate or DI quality and free of hardness, transition metals, and chlorine) is required to remove all traces of chemical from the Cleaning Skid and the RO Skid. Drain and flush the cleaning tank; then completely refill the Cleaning Tank with clean water for the Cleaning Rinse. Rinse the pressure tubes by pumping all of the rinse water from the Cleaning Tank through the pressure tubes to drain. A second cleaning can be started at this point, if required.
6. Once the RO system is fully rinsed of cleaning chemical with clean water from the Cleaning Tank, a Final Low Pressure Clean-up Flush can be performed using pretreated feed water. The permeate line should remain open to drain. Feed pressure should be less than 60 psi (4 Kg/cm²). This final flush continues until the flush water flows clean and is free of any foam or residues of cleaning agents. This usually takes 15 to 60 minutes. The operator can sample the flush water going to the drain for detergent removal and lack of foaming by using a clear flask and shaking it. A conductivity meter can be used to test for removal of cleaning chemicals, such that the flush water to drain is within 10-20% of the feed water conductivity. A pH meter can also be used to compare the flush water to drain to the feed pH.
7. Once all the stages of a train are cleaned, and the chemicals flushed out, the RO can be restarted and placed into a Service Rinse. The RO permeate should be diverted to drain until it meets the quality requirements of the process (e.g. conductivity, pH, etc.). It is not unusual for it to take from a few hours to a few days for the RO permeate quality to stabilize, especially after high pH cleanings.

Maintenance

Membrane Shutdown, and Preservative Flushing Guidelines Biocides for Disinfection and Storage of Supplied ESPA1 Hydranautics Membrane Elements

One should confirm which brand and type of membrane elements are actually in the system. Since elements may be composed of composite polyamide membrane types it is imperative to be certain of the type to be disinfected. If any uncertainty exists regarding the type of elements in use, please contact the membrane supplier for confirmation of compatibility of specific procedures with membrane types. If the feed water contains any hydrogen sulfide or dissolved iron or manganese, oxidizing disinfectants such as hydrogen peroxide should not be used.



WARNING

The biocides listed in this procedure are toxic in some degree to humans. Allow ample time for system flushing, from 2 to 24 hours, to remove the presence of the biocides before starting normal operation. It is the responsibility of the end user to ensure that the system is properly flushed for each application. Pentair assumes no liability for the misuse of any chemical listed herein, and all safety issues are the responsibility of the end user. Consult manufacturers' Material Safety Data Sheets (MSDS's) for proper handling and disposal of any of the listed chemicals.

Biocides which can be used with Composite Polyamide ESPA1 Membrane Elements

Isothiazolin

Isothiazolin is distributed by manufacturers of water treatment chemicals under the trade name Kathon. The commercial solution contains 1.5% of the active ingredient. The recommended concentration of Kathon for disinfection and storage is 15 to 25 ppm.

Sodium Bisulfite

Sodium bisulfite (SBS) can be used as an inhibitor of biological growth. To control biological growth with sodium bisulfite, it is applied at a dosing rate of 500 ppm for 30 to 60 minutes daily. The membrane must be flushed for 2-24 hours after dosing the membrane with SBS. Sodium bisulfite at a 1% concentration can also be used as a preservative during long term storage of the membrane elements.

General Storage Procedures for Composite Polyamide ESPA1 RO Membrane Elements

Guidelines for storing the supplied Hydranautics' ESPA1 Composite Polyamide Reverse Osmosis (RO) membrane elements.

NOTE: Before undertaking any long-term or short-term storage operation, contact Hydranautics for specific instructions related to the local environment.

The general storage procedures included in this bulletin are as follows:

- A. Short-term storage of RO membrane elements in place in membrane housings.
- B. Long-term storage of RO membrane elements in place in membrane housings.
- C. Dry storage of RO membrane elements as spares, prior to installation or before start-up.

NOTE: The composite polyamide type of RO membrane elements supplied may not be exposed to chlorinated water under any circumstances. Any such exposure will cause irreparable damage to the membrane. Absolute care must be taken following any disinfection of piping or equipment or the preparation of cleaning or storage solutions to ensure that no trace of chlorine is present in feedwater to the RO membrane elements. If there is any doubt about the presence of chlorine, perform chemical testing to make sure. Neutralize any chlorine residual with a sodium bisulfite solution, and ensure adequate contact time to accomplish complete dechlorination.

A. Short-Term Storage

Short-term storage is for periods where an RO system must remain out of operation for more than five days, but fewer than thirty days, with the RO elements in place. Prepare each RO train as follows:

1. Flush the RO section with feedwater, while simultaneously venting any gas from the system. Flushing with RO permeate water instead of feedwater has added benefits, and may help remove build up of foulants.
2. When the pressure tubes are filled, close the appropriate valves to prevent air from entering the system.
3. Reflush as described above at 5-day intervals.

B. Long-Term Storage

Long-term storage is for periods where an RO system must remain out of operation for more than thirty days with the RO elements in place. Prepare each RO train as follows:

1. Clean the RO membrane elements in place with Sodium Bisulfite or Isothiazolin (Kathon).
2. Flush the RO section with an approved biocide or check with Hydranautics for recommendations and approvals of currently available products) prepared from permeate.
3. When the RO section is filled with this solution (make sure that it is completely filled), close the valves to retain the solution in the RO section.
4. Repeat Steps 2 and 3 with fresh solution every thirty days if the temperature is below 80°F (27°C), or every fifteen days if the temperature is above 80°F (27°C).
5. When the RO system is ready to be returned to service, flush the system for approximately 2-24 hours with the product dump valve open to drain or temporary piping plumbed to the drain with the appropriate air-gap. Before returning the RO system to service, check for any residual biocide in the product.

C. Prior To Installation

When RO elements are stored prior to installation, they should be protected from direct sunlight and stored in a cool, dry place with an ambient temperature range of 40°F to 95°F (4.4°C to 35°C). During the period of transit between the factory and the plant site, the elements should not be exposed to temperatures below freezing, 32°F (0°C), or above 113°F (45°C). New Elements are enclosed in a sealed polyethylene bag containing a storage solution, and then packaged in a cardboard box.

Maintenance

Length of Storage

RO elements are typically stored with a preservative solution and enclosed in a vacuum sealed bag. The preservative is sodium bisulfite (SBS) with propylene glycol. Only store RO membranes up to 1 year after purchase. Elements could be stored for an extended period of time and still perform as expected. If the storage conditions listed above are followed and the vacuum in the bag is maintained, it may be possible to successfully store elements in excess of three years which is not recommended and not covered under warranty. Installation of elements which are stored for such long periods may result in lower flow rates or higher operating pressures than expected. In such instances, it is recommended to clean the elements using a caustic solution, as outlined in (Solution 7), in order to improve flux.

Sanitizing

Based on the application, sanitizing may be needed.

Always clean membranes prior to sanitizing system. For most normal applications, cleaning at low and high pH levels provides suitable sanitization.

For special applications, seek advice from the local systems provider regarding how to sanitize.

Storing the Unit

Always clean membranes prior to storing unit.

Membrane Replacement

Membranes may require early replacement because of irreversible fouling. Failure to clean on time or a foulant not previously defined will cause most problems. Cleaning is based on the known contaminants that were found when the inlet water was tested. It is important to know the cause of the problem to prevent future early membrane replacements. Silica, oil, cationic surfactants, polymers, etc. may be some of the probable culprits. Operating Log data will be of great help to define the potential culprit.

Brackish Water: Brackish water is defined as a fresh low TDS water source that experiences a large increase in normal TDS due to seawater intrusion. In regards to RO, brackish water is defined as feed water with low to medium TDS levels (up to 10,000 to 15,000 ppm) that can be treated with a “brackish RO element” designed for 600 psi maximum applied feed pressure.

Concentrate Water: Also known as brine, reject or drain water. It is the water that doesn't go through the semipermeable membrane and carries the concentrated ions to drain.

Concentrating Factor (CF): Is the number of times that the TDS of the RO feed water is concentrated in the reject water. Where SR = Salt Rejection and R = Recovery.

$$CF = \%SR / (1 - R)$$

Grains (per gallon): Ion exchange and boiler water chemists report the concentration of hardness as “Grains per Gallon (as calcium carbonate equivalents)”. One Grain per U.S. Gallon (as calcium carbonate) is equal to 17.1 ppm (as calcium carbonate).

mg/l: A method of reporting the “actual” weight (milligrams) of an ion or substance in a given volume of water (liter). For dilute solutions, mg/l and ppm are equivalent. For example, a 1,000 mg/l (ppm) sodium chloride solution would result in a residue of 1,000 mg of NaCl after evaporation of one liter of water. RO chemists use mg/l frequently in the calculation of TDS

Permeate Water: It is the water that passes through a semipermeable reverse osmosis membrane.

pH: The pH of the feed water measures the acidity or basicity. A pH of 7.0 is considered neutral. A pH between 0.0 and 7.0 is acidic. A pH between 7.0 and 14.0 is basic. To the analytical chemist, pH is a method of expressing hydrogen ion concentration in terms of the power of 10 with the pH value being the negative logarithm of the hydrogen ion concentration. To the water chemist, pH is important in defining the alkalinity equilibrium levels of carbon dioxide, bicarbonate, carbonate and hydroxide ions. The concentrate pH is typically higher than the feed due to the higher concentration of bicarbonate/carbonate ions relative to the concentration of carbon dioxide. The user can adjust the pH of the feed water using hydrochloric or sulfuric acid. Lowering the feed pH with acid results in a lower LSI (Langlier Saturation Index) value, which reduces the scaling potential for calcium carbonate. Feed and concentrate (reject) pH can also effect the solubility and fouling potential of silica, aluminum, organics and oil. Variations in feed pH can also affect the rejection of ions. For example, fluoride, boron and silica rejection are lower when the pH becomes more acidic.

ppm (parts per million): A method for reporting the concentration of an ion or substance in a water. The following conversions apply for dilute waters with a specific gravity of 1.0: One ppm is equal to one mg/L. One Grain per U.S. Gallon is equal to 17.1 ppm. One Pound per 1,000 U.S. Gallons is equal to 120 ppm. A one per cent solution is equal to 10,000 ppm. One ppm is equal to 1,000 ppb.

ppm as CaCO₃: A method of reporting the concentration or “equivalent” weight of an ion or substance in a given volume of water as “ppm as calcium carbonate”. Reporting the concentration of ions as “ppm as calcium carbonate” is popular by ion exchange chemists for the calculation of ionic loading of cation or anion resins. It is also popular in determining whether a water analysis is “balanced” where the sum of the cations equals the sum of the anions when the concentration of the ions are reported as calcium carbonate equivalents. Water chemists use the concept of “equivalency” when balancing cation and anion electroneutrality levels since ions combine in nature based on their valence state and available electrons, not on their “actual” weight. Calcium carbonate was arbitrarily picked because its molecular weight is 100 and its equivalent weight is 50 since it is divalent. The formula to convert an ion reported as “mg/l as the ion” to “ppm as calcium carbonate” is to multiply “mg/l as the ion” times the ratio of the “equivalent weight of the ion” by the “equivalent weight of calcium carbonate”. As an example, a water with sodium at 100 ppm as calcium carbonate and chloride at 100 ppm as calcium carbonate are in ionic balance since every sodium ion has a corresponding chloride ion. However, sodium concentration at 100 ppm as calcium carbonate is only 47 mg/l of actual substance (since its equivalent weight is 23.0) and 100 ppm of chloride as calcium carbonate is only 71 mg/l of actual substance (since its equivalent weight is 35.5). The calculated TDS of this solution is 118 mg/l.

Raw Water: Water entering into a water treatment system that may be coming directly from a municipal system or directly from sources such as rivers, lakes, wells, etc.

Recirculating Water: A term sometimes used in pumps, in this manual it refers to a portion of the reject water coming out of the last membrane element(s) that it is brought back to be blended with the RO feed water to make the membrane feed water.

Glossary

RO Feed Water: Water entering into a reverse osmosis system. In the case of having a recirculating system, membrane feed water will be the blend of the RO feed water and the recirculating water.

Silica (SiO₂): Silica (silicon dioxide), in some cases, is an anion. The chemistry of silica is a complex and somewhat unpredictable subject. In similar fashion as TOC reports the total concentration of organics (as carbon) without detailing what the organic compounds are, silica reports the total concentration of silicon (as silica) without detailing what the silicon compounds are. The "Total Silica" content of water is composed of "Reactive Silica" and "Unreactive Silica". Reactive silica (e.g. silicates SiO₄) is dissolved silica that is slightly ionized and has not been polymerized into a long chain. Reactive silica is the form that RO and ion exchange chemists hope for. Reactive silica is the form of silica to be used in RO projection programs. Reactive silica, though it has anionic characteristics, is not counted as an anion in terms of balancing a water analysis but it is counted as a part of total TDS. Unreactive silica is polymerized or colloidal silica, acting more like a solid than a dissolved ion. Silica, in the colloidal form, can be removed by a RO but it can cause colloidal fouling of the front-end of a RO. Colloidal silica, with sizes as small as 0.008 micron can be measured empirically by the SDI (Silt Density Index) test, but only that portion that is larger than 0.45 micron or larger. Particulate silica compounds (e.g. clays, silts and sand) are usually 1 micron or larger and can be measured using the SDI test. Polymerized silica, which uses silicon dioxide as the building block, exists in nature (e.g. quartzes and agates). Silica, in the polymerized form, also results from exceeding the reactive silica saturation level. The solubility of reactive silica is typically limited to 200-300% with the use of silica dispersant. Reactive silica solubility increases with increasing temperature, increases at a pH less than 7.0 or more than 7.8, and decreases in the presence of iron which acts as a catalyst in the polymerization of silica. Silica rejection is pH sensitive, with increasing rejection at a more basic pH as the reactive silica exists more in the salt form than in the acidic form.

TDS (Total Dissolved Solids): TDS, in water treatment, is the inorganic residue left after the filtration of colloidal and suspended solids and then the evaporation of a known volume of water. TDS is reported as ppm or mg/l. TDS, in RO design projections, is determined by calculation using the sum of the cations, anions and silica ions (with the ion reported "as such", not "as calcium carbonate"). Feed or permeate TDS, in RO design projections, can also be estimated by applying a conversion factor to the conductivity of the solution. TDS can also be determined in the field by use of a TDS meter. TDS meters measure the conductivity of the water and then apply a conversion factor that reports TDS to a known reference solution (e.g. ppm sodium chloride or ppm potassium chloride). The user is cautioned that TDS levels for waters with a mixture of ions and determined from conductivity measurements may not agree with TDS calculated as a sum of the ions. As a rough rule of thumb, one ppm of TDS (when referenced to a NaCl solution) correlates to a conductivity of two micromhos/cm (microSiemens/cm).

Temperature: Temperature is a critical design parameter. It has significant effects on feed pump pressure requirements, hydraulic flux balance between stages, permeate quality, and solubility of sparingly soluble salts. As a rough rule of thumb, every 10-degree Fahrenheit decrease in feed temperature increases the feed pump pressure requirement 15 %. The hydraulic flux balance between stages (or in other words the amount of permeate produced by each stage) is impacted by temperature. When water temperature increases, the elements located in the front end of the system produce more permeate which results in reduced permeate flow by the elements located at the rear of the system. A better hydraulic flux balance between stages occurs at colder temperatures. At warmer temperatures, salt passage increases due to the increased mobility of the ions through the membrane. Warmer temperatures decrease the solubility of calcium carbonate. Colder temperatures decrease the solubility of calcium sulfate, barium sulfate, strontium sulfate, and silica.

Turbidity: Turbidity is a suspension of fine colloidal particles that do not readily settle out of solution and can result in "cloudiness". Turbidity is determined by a Nephelometer that measures the relative amount of light able to pass through a solution with the amount of light scattered at an angle of 90 degrees. Turbidity is reported as NTU (Nephelometric Turbidity Units). Typical RO element warranties list a maximum of 1.0 NTU for the feed water.

% Recovery (%R): It defines how efficient the reverse osmosis system is on producing permeate (clean) water. R, the recovery is used to calculate the system's concentrating factor.




$$\%R = (\text{permeate water, in gpm})/(\text{RO feed water, in gpm})$$

% Salt Rejection (%SR): The percentage of salt in the RO feed water that is rejected by the reverse osmosis membrane.


$$\%SR = [1 - (\text{permeate water TDS}/\text{feed water TDS})] \times 100$$

[illegible]

COMPONENTS LIST	
(P1)	PREFILTER PRESSURE
(P2)	POSTFILTER PRESSURE
(P3)	SUPPLY PRESSURE
(P4)	REJECT PRESSURE
(S1)	SOLENOID ENTRY 3/4"
(S2)	SOLENOID AUTO FLUSHING 1/2" NPT

COMPONENTS LIST	
V1	VALVE (NEEDLE) 1/2" NPT
V2	RECYCLE VALVE
	CHECK VALVE 1/2" NPT
	VALVE GLOBE
	HIGH PRESSURE PUMP BERKELEY MGF10E

HighPure Deluxe RO System Layout - 2 Membranes



COMPONENTS LIST	
P1	PREFILTER PRESSURE
P2	POSTFILTER PRESSURE
P3	SUPPLY PRESSURE
P4	REJECT PRESSURE
S1	SOLENOID ENTRY 3/4"
S2	SOLENOID AUTO FLUSHING 1/2" NPT

COMPONENTS LIST	
V1	VALVE (NEEDLE) 1/2" NPT
V2	RECYCLE VALVE
	CHECK VALVE 1/2" NPT
	VALVE GLOBE
	HIGH PRESSURE PUMP BERKELEY MGP510E

1 PREFILTER PRESSURE
2 HOUSING 3/4"X20"
3 POSTFILTER PRESSURE
4 SOLENOID ENTRY 3/4" NPT
5 HIGH PRESSURE PUMP 1HP
6 PERMEATE COLLECTOR
7 SUPPLY PRESSURE
8 MEMBRANE HOUSING 4"X40"
9 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
10 SOLENOID AUTO FLUSHING 3/4" NPT
11 VALVE (NEEDLE) 1/2" NPT
12 REJECT FLOWMETER .5-5 GPM, 1/2" NPT
13 CONDUCTIVITY CELL
14 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
15 CHECK VALVE 1/2" NPT
16 REJECT PRESSURE

17 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
18 PERMEATE COLLECTOR
19 CONDUCTIVITY CELL
20 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
21 CHECK VALVE 1/2" NPT
22 REJECT PRESSURE
23 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
24 PERMEATE COLLECTOR
25 CONDUCTIVITY CELL
26 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
27 CHECK VALVE 1/2" NPT
28 REJECT PRESSURE

29 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
30 PERMEATE COLLECTOR
31 CONDUCTIVITY CELL
32 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
33 CHECK VALVE 1/2" NPT
34 REJECT PRESSURE

35 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
36 PERMEATE COLLECTOR
37 CONDUCTIVITY CELL
38 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
39 CHECK VALVE 1/2" NPT
40 REJECT PRESSURE

41 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
42 PERMEATE COLLECTOR
43 CONDUCTIVITY CELL
44 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
45 CHECK VALVE 1/2" NPT
46 REJECT PRESSURE

47 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
48 PERMEATE COLLECTOR
49 CONDUCTIVITY CELL
50 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
51 CHECK VALVE 1/2" NPT
52 REJECT PRESSURE

53 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
54 PERMEATE COLLECTOR
55 CONDUCTIVITY CELL
56 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
57 CHECK VALVE 1/2" NPT
58 REJECT PRESSURE

59 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
60 PERMEATE COLLECTOR
61 CONDUCTIVITY CELL
62 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
63 CHECK VALVE 1/2" NPT
64 REJECT PRESSURE

65 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
66 PERMEATE COLLECTOR
67 CONDUCTIVITY CELL
68 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
69 CHECK VALVE 1/2" NPT
70 REJECT PRESSURE

71 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
72 PERMEATE COLLECTOR
73 CONDUCTIVITY CELL
74 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
75 CHECK VALVE 1/2" NPT
76 REJECT PRESSURE

77 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
78 PERMEATE COLLECTOR
79 CONDUCTIVITY CELL
80 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
81 CHECK VALVE 1/2" NPT
82 REJECT PRESSURE

83 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
84 PERMEATE COLLECTOR
85 CONDUCTIVITY CELL
86 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
87 CHECK VALVE 1/2" NPT
88 REJECT PRESSURE

89 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
90 PERMEATE COLLECTOR
91 CONDUCTIVITY CELL
92 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
93 CHECK VALVE 1/2" NPT
94 REJECT PRESSURE

95 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
96 PERMEATE COLLECTOR
97 CONDUCTIVITY CELL
98 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
99 CHECK VALVE 1/2" NPT
100 REJECT PRESSURE

101 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
102 PERMEATE COLLECTOR
103 CONDUCTIVITY CELL
104 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
105 CHECK VALVE 1/2" NPT
106 REJECT PRESSURE

107 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
108 PERMEATE COLLECTOR
109 CONDUCTIVITY CELL
110 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
111 CHECK VALVE 1/2" NPT
112 REJECT PRESSURE

113 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
114 PERMEATE COLLECTOR
115 CONDUCTIVITY CELL
116 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
117 CHECK VALVE 1/2" NPT
118 REJECT PRESSURE

119 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
120 PERMEATE COLLECTOR
121 CONDUCTIVITY CELL
122 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
123 CHECK VALVE 1/2" NPT
124 REJECT PRESSURE

125 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
126 PERMEATE COLLECTOR
127 CONDUCTIVITY CELL
128 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
129 CHECK VALVE 1/2" NPT
130 REJECT PRESSURE

131 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
132 PERMEATE COLLECTOR
133 CONDUCTIVITY CELL
134 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
135 CHECK VALVE 1/2" NPT
136 REJECT PRESSURE

137 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
138 PERMEATE COLLECTOR
139 CONDUCTIVITY CELL
140 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
141 CHECK VALVE 1/2" NPT
142 REJECT PRESSURE

143 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
144 PERMEATE COLLECTOR
145 CONDUCTIVITY CELL
146 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
147 CHECK VALVE 1/2" NPT
148 REJECT PRESSURE

149 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
150 PERMEATE COLLECTOR
151 CONDUCTIVITY CELL
152 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
153 CHECK VALVE 1/2" NPT
154 REJECT PRESSURE

155 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
156 PERMEATE COLLECTOR
157 CONDUCTIVITY CELL
158 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
159 CHECK VALVE 1/2" NPT
160 REJECT PRESSURE

161 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
162 PERMEATE COLLECTOR
163 CONDUCTIVITY CELL
164 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
165 CHECK VALVE 1/2" NPT
166 REJECT PRESSURE

167 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
168 PERMEATE COLLECTOR
169 CONDUCTIVITY CELL
170 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
171 CHECK VALVE 1/2" NPT
172 REJECT PRESSURE

173 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
174 PERMEATE COLLECTOR
175 CONDUCTIVITY CELL
176 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
177 CHECK VALVE 1/2" NPT
178 REJECT PRESSURE

179 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
180 PERMEATE COLLECTOR
181 CONDUCTIVITY CELL
182 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
183 CHECK VALVE 1/2" NPT
184 REJECT PRESSURE

185 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
186 PERMEATE COLLECTOR
187 CONDUCTIVITY CELL
188 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
189 CHECK VALVE 1/2" NPT
190 REJECT PRESSURE

191 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
192 PERMEATE COLLECTOR
193 CONDUCTIVITY CELL
194 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
195 CHECK VALVE 1/2" NPT
196 REJECT PRESSURE

197 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
198 PERMEATE COLLECTOR
199 CONDUCTIVITY CELL
200 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
201 CHECK VALVE 1/2" NPT
202 REJECT PRESSURE

203 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
204 PERMEATE COLLECTOR
205 CONDUCTIVITY CELL
206 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
207 CHECK VALVE 1/2" NPT
208 REJECT PRESSURE

209 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
210 PERMEATE COLLECTOR
211 CONDUCTIVITY CELL
212 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
213 CHECK VALVE 1/2" NPT
214 REJECT PRESSURE

215 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
216 PERMEATE COLLECTOR
217 CONDUCTIVITY CELL
218 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
219 CHECK VALVE 1/2" NPT
220 REJECT PRESSURE




221 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
222 PERMEATE COLLECTOR
223 CONDUCTIVITY CELL
224 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
225 CHECK VALVE 1/2" NPT
226 REJECT PRESSURE

227 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
228 PERMEATE COLLECTOR
229 CONDUCTIVITY CELL
230 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
231 CHECK VALVE 1/2" NPT
232 REJECT PRESSURE


233 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
234 PERMEATE COLLECTOR
235 CONDUCTIVITY CELL
236 ADJUSTABLE FLOWMETER 1-10 GPM, 3/4" NPT
237 CHECK VALVE 1/2" NPT
238 REJECT PRESSURE

239 PERMEATE FLOWMETER .5-5 GPM, 1/2" NPT
240 PERMEATE COLLECTOR
241 CONDUCTIVITY CELL
242 ADJUSTABLE FLOWM


COMPONENTS LIST	
(P1)	PREFILTER PRESSURE
(P2)	POSTFILTER PRESSURE
(P3)	SUPPLY PRESSURE
(P4)	REJECT PRESSURE
(S1)	SOLENOID ENTRY 3/4"
(S2)	SOLENOID AUTO FLUSHING 3/4"

COMPONENTS LIST	
V1	VALVE (NEEDLE) 1/2" NPT
V2	RECYCLE VALVE
	CHECK VALVE 1/2" NPT
	VALVE GLOBE
	HIGH PRESSURE PUMP BERKELEY MAPS10E

HighPure Deluxe RO System Layout - 4 Membranes




HighPure Deluxe RO System Layout - 5 Membranes






COMPONENTS LIST	
V1	VALVE (NEEDLE) 1" NPT
V2	RECYCLE VALVE
	CHECK VALVE 3/4" NPT
	VALVE GLOBE
	HIGH PRESSURE PUMP BERKELEY MOPS20E

COMPONENTS LIST	
P1	PREFILTER PRESSURE
P2	POSTFILTER PRESSURE
P3	SUPPLY PRESSURE
P4	REJECT PRESSURE
S1	SOLENOID ENTRY 1"
S2	SOLENOID AUTO FLUSHING 3/4"

Page 44



COMPONENTS LIST	
V1	VALVE (NEEDLE) 1" NPT
V2	RECYCLE VALVE
	CHECK VALVE 3/4" NPT
	VALVE GLOBE
	HIGH PRESSURE PUMP BERKELEY MOPSODE

Silt Density Index (SDI)

Suspended solids, insoluble precipitants and colloidal materials in feed water are one of the biggest problems in reverse osmosis systems. Even though most systems have some pretreatment including prefilters, fine particles are responsible for fouling of reverse osmosis membranes.

In order to have some measure of the degree of this fouling problem, Silt Density Index (SDI) is used.

A SDI of less than 3 is considered acceptable for the reverse osmosis systems. This means that SDI values of less than five, should foul the membranes at a very low rate.

Membrane Fouling Control

Membrane fouling is the main cause of permeate decline and loss of product quality in reverse osmosis (RO) Systems. Sources of fouling can be divided into four principal categories: scale, silt (particulates), silica, bacterial (bio fouling, growth of bacteria) and organic fouling (oil, grease).

Control over fouling involves pre-treatment of the feed water to minimize fouling. Fouling by particulates (silt), bacteria, silica and organics generally affects the first modules the most. Scaling is worse with more concentrated feed solutions, therefore the last modules are most affected.


Silt Density Index

Silt is composed of suspended particulates of all types that accumulate on the RO membrane surface. Sources of silt are organic colloids, iron corrosion products, precipitated iron hydroxide, algae and fine particulates. Silt Density Index testing is a widely accepted method for estimating the rate at which colloidal and particle fouling will occur in reverse osmosis water purification systems.

SDI is a measurement of the fouling potential of suspended solids. Turbidity is a measurement of the amount of suspended solids. They are not the same and there is no direct correlation between the two. In practice the membranes show very little fouling when the feed water has a turbidity of <1NTU.

The SDI test measures the time required to filter a fixed volume of water through a standard 0.45µm pore size microfiltration membrane with a constant given pressure of 30 psi (2.1 Kg/cm²). The SDI value is the difference between the test time in seconds of the first test and a second measurement after normally 15 minutes of filtering SDI (SD15).

Water temperature should be kept close to normal and within $\pm 1^\circ\text{F}$.



Silt Density Index (SDI)

The feed water has to be supplied with a pressure of 30 psi (2.1 Kg/cm²), which will be regulated with the pressure regulator and reading off the value on the pressure gauge.

Measure the amount of time in seconds required for 500 ml of feed water to flow through the filter.

The water should continue to flow with a pressure of 30 psi (2.1 Kg/cm²) through the filter.

After 15 minutes measure again the time in seconds required for 500 ml of feed water to pass the filter. The 15-minute index should be used for filter sizing purpose.

The 15-minute SDI (SDI 15) is defined by ASTM as the interval required for accurate and standardized testing.

How to Calculate Silt Density Index and Plugging Factor

After completing the test, calculate the SDI by using the equation below.

$$SDI = \frac{100 * (1 - t_i / t_f)}{t_t}$$

t_i = Initial time in seconds required to collect the 500 ml sample

t_f = Final time in seconds required to collect the second sample after test time

t_t = Total elapsed test time (either 5, 10 or 15 min)


HighPure Deluxe Specifications

Model	CMDLX1M	CMDLX2M	CMDLX3M	CMDLX4M	CMDLX5M	CMDLX6M
Nominal Capacity: gpd (m³/day)	1800–2040 (6.7–7.7)	3600–4080 (13.7–15.4)	5400–6120 (19.2–23.2)	7200–8160 (27.4–30.9)	9000–10200 (34.1–38.6)	10800–12240 (40.8–46.3)
System Recovery	38–71%	33–75%	43–75%	33–75%	39–75%	43–75%
Permeate Rate: gpm (m³/hr)	1.25–1.42 (0.28–0.32)	2.5–2.83 (0.57–0.64)	3.75–4.25 (0.80–0.97)	5.0–5.67 (1.14–1.29)	6.25–7.08 (1.42–1.61)	7.5–8.5 (1.70–1.93)
Concentrate Rate: gpm (m³/hr)	2.0–0.58 (0.46–0.13)	5.0–0.94 (1.13–0.21)	5.0–1.42 (1.13–0.32)	10–1.89 (2.27–0.42)	10–2.36 (2.27–0.53)	10–2.83 (2.27–0.64)
Feed Water Rate: gpm (m³/hr)	3.25–2.0 (0.74–0.45)	7.5–3.77 (1.7–0.85)	8.75–5.67 (2.0–1.28)	15–7.56 (3.41–1.71)	16.25–9.44 (3.69–2.14)	17.5–11.33 (3.97–2.57)
Dynamic Feed Water Inlet Pressure - Min: psi (Kg/cm²)	40 psi (2.8)					
Feed Water Inlet Pressure - Max: psi (Kg/cm²)	80 psi (5.6)					
Standard Feed Water Temperature: °F (°C)	35–104 (2–40)					
Membranes						
Membrane Size: nominal inches	4 x 40					
Membrane Quantity	1	2	3	4	5	6
Elements Array	1	1–1	1–1–1	2–2	2–2–1	2–2–2
Nominal Salt Rejection	95-99%					
Vessel Material	Stainless Steel					
Piping						
Inlet: inches (mm)	3/4 (19)			1 (25)		
Permeate Outlet: inches (mm)	1/2 (13)			3/4 (19)		
Concentrate Outlet: inches (mm)	1/2 (13)			3/4 (19)		
Pump						
Centrifugal Pump	(MGPS10E)			(MGPS20G)		
Boost Pressure: psi (Kg/cm²)	80–220 (5.6–15.5)					
Pump Material	Stainless Steel					
Horsepower (KW)	1 (0.75)			2 (1.49)		
Voltage 60 Hz, Single Phase	230					
Amps	11			13		
System Dimensions						
Height: inches (cm)	66 (168)					
Width: inches (cm)	25 (64)		28 (71)		40 (102)	
Depth: inches (cm)	20 (51)		23 (59)		25 (64)	
Weight of System Without Water: lbs (Kg)	155 (71)	180 (82)	255 (116)	280 (127)	320 (145)	345 (157)
Filter Dimensions						
Filter Housing Quantity & Size: inches	1–2.9 x 20			1–4.5 x 20		
Versaflex™ Replacement Filter	VF5-20BMXXXDX			VF5-20FGXXXDX		
Standard Feed Water Quality Requirements						
Softened Water	<1 grain / gallon					
Silt Density Index (SDI)	SDI < 3					
Total Dissolve Solids (TDS)	TDS < 2000					
Silica: ppm	SiO ₂ < 20					
Turbidity: NTU	Turbidity < 1.0					
pH	pH = 3 to 10					
Iron & Manganese: ppm	< 0.01					
Chlorine/Chloramine - Max: mg/l	<0.01					
Chloride: ppm	<350					

Controller Specifications

Power:		240 VAC -15%+10%, 60 Hz, 6 watts
Display:		3 digit red LED for measuring TDS
Switch Inputs, Dry Contact, Normally Open:		
	Pressure fault Pretreat lockout Tank full	
Relay Outputs:		
	RO pump relay Inlet valve relay Flush valve relay	240 VAC/3 HP 240 VAC, 5 A 240 VAC, 5 A
	Relays supply same output voltage as board power (240 VAC)	

Ordering Information



Item	Description
1	High Pressure Pump
2	Membrane Housing
3	Prefilter Inlet Gauge
4	Prefilter Outlet Gauge
5	Membrane Feed Gauge
6	Concentrate Gauge
7	Prefilter
8	Concentrate Flow Meter

Item	Description
9	Permeate Flowmeter
10	Adjustable Recycle Flowmeter
11	Conductivity Display
12	Control
13	Concentrate Control Valve
14	Solenoid Inlet
15	Solenoid Flushing

Ordering Information

Part Number	Standard Systems and Parts
CM801005	HighPure RO CMDLX1M
CM801006	HighPure RO CMDLX2M
CM801007	HighPure RO CMDLX3M
CM801008	HighPure RO CMDLX4M
CM801009	HighPure RO CMDLX5M
CM801010	HighPure RO CMDLX6M
CM490001	Motor, 230V Single Phase, 1 HP
CM490002	Motor, 230V, Single Phase 2 HP
CM490003	Pump Rebuild Kit, 1 HP
CM490004	Pump Rebuild Kit, 2 HP
CM490012	Versaflex™ VF5-20BMXXDX 25/Case
CM490013	Versaflex™ VF5-20FGXXDX 12/Case
CM490005	Membrane, RO, 2500 gpd, 4" dia. x 40" length
CM490008	Pump, Booster, Stainless Steel, 1 HP, 10 gpm
CM490010	Pump, Booster, Stainless Steel, 2 HP, 20 gpm
CM400085	Valve, Solenoid, 230 Vac, 1/2" Connection
CM400086	Valve, Solenoid, 230 Vac, 3/4" Connection
CM400087	Valve, Solenoid, 230 Vac, 1" Connection
CM200001	Deluxe RO Manual
M490014	SW-2 Wrench 20"
M490015	SW-4 Wrench 20" BB

Appendix A - Temperature Correction

Temperature of the feed water across the element must be taken into account before comparing or evaluating the performance of a membrane element or a reverse osmosis system.

Temperature Correction Factor

The water temperature is one of the key factors in the performance of the reverse osmosis membrane element. The higher the temperature, the more the product flow, and the lower the temperature the lower the flow. All reverse osmosis membrane elements and systems are rated at 77°F (25°C). Operating the system at pressures and temperatures different than the ones designed will change the permeate flow.

If system is running at a different temperature than the standard, a product flow calculation should be made. A membrane's productivity changes substantially with temperature.

The expected permeate at 77°F is 5 gpm. If your water temperature is different than 77°F divide or multiply the expected flow (5 gpm) by the temperature correction factor from the table below to determine the actual flow.

Example:

60°F (15.6°C) water temp

$$5 / 1.34 = 3.73 \text{ gpm}$$

$$5 \times 0.75 = 3.75 \text{ gpm}$$

Permeate Temperature Correction Factors		
Running Water Temperature °F (°C)	Divisor	Multiplier
35 (2.0)	2.16	0.46
40 (4.4)	1.96	0.51
45 (7.2)	1.78	0.56
50 (10.0)	1.62	0.62
55 (12.8)	1.47	0.68
60 (15.6)	1.34	0.75
65 (18.3)	1.23	0.81
70 (21.1)	1.13	0.88
75 (23.9)	1.03	0.97
77 (25.0)	1.00	1.00
80 (26.7)	0.95	1.05
85 (29.4)	0.88	1.14
90 (32.2)	0.81	1.23
95 (35.0)	0.75	1.33
100 (38.0)	0.69	1.45
104 (40.0)	0.65	1.54

Appendix B - Conductivity, Resistivity and TDS Conversion Chart

Conductivity Microsiemens-cm or Micromhos-cm @25°C	Resistivity Ohms-cm @25°C	Meg Ohms-cm or Siemen-cm	Controller Display Dissolved Solids Parts per Million (ppm)	Approximate Grains/Gallon (Gpg) as CaCO ₃
0.056	18,000,000	18.0	0.0277	0.00164
0.059	17,000,000	17.0	0.0294	0.00170
0.063	16,000,000	16.0	0.0313	0.00181
0.067	15,000,000	15.0	0.0333	0.00193
0.072	14,000,000	14.0	0.0357	0.00211
0.077	13,000,000	13.0	0.038	0.00222
0.084	12,000,000	12.0	0.0417	0.00240
0.091	11,000,000	11.0	0.0455	0.00263
0.100	10,000,000	10.0	0.0500	0.00292
0.111	9,000,000	9.0	0.0556	0.00322
0.125	8,000,000	8.0	0.0625	0.00358
0.143	7,000,000	7.0	0.0714	0.00415
0.167	6,000,000	6.0	0.0833	0.00485
0.200	5,000,000	5.0	0.100	0.00585
0.250	4,000,000	4.0	0.125	0.00731
0.333	3,000,000	3.0	0.167	0.00971
0.500	2,000,000	2.0	0.250	0.0146
1.00	1,000,000	1.0	0.500	0.0292
1.11	900,000	0.9	0.556	0.0322
1.25	800,000	0.8	0.625	0.0368
1.43	700,000	0.7	0.714	0.0415
1.67	600,000	0.6	0.833	0.0485
2.00	500,000	0.5	1.00	0.0585
2.50	400,000	0.4	1.25	0.0731
3.33	300,000	0.3	1.67	0.0971
5.00	200,000	0.2	2.50	0.146
10.0	100,000	0.1	5.00	0.292
11.1	90,000	0.09	5.58	0.322
12.5	80,000	0.08	6.25	0.368
14.3	70,000	0.07	7.14	0.415
16.7	60,000	0.06	8.33	0.485
20.0	50,000	0.05	10.0	0.585
25.0	40,000	0.04	12.5	0.731
33.3	30,000	0.03	16.7	0.971
50.0	20,000	0.02	25.0	1.46
100.0	10,000	0.01	50.0	2.92
111	9,000	0.009	55.6	3.22
125	8,000	0.008	62.5	3.68
143	7,000	0.007	71.4	4.15
167	6,000	0.006	83.3	4.85
200	5,000	0.005	100	5.85
250	4,000	0.004	125	7.31
333	3,000	0.003	167	9.71
500	2,000	0.002	250	14.6
1,000	1,000	0.001	500	29.2
1,110	900	0.0009	556	32.2
1,250	800	0.0008	625	36.8
1,430	700	0.0007	714	41.5
1,670	600	0.0006	833	48.5
2,000	500	0.0005	1,000	58.5
2,500	400	0.0004	1,250	73.1
3,330	300	0.0003	1,670	97.1
5,000	200	0.0002	2,500	146
10,000	100	0.0001	5,000	292

Note: All non-charged (non-ionic) materials will not be registered by conductivity/TDS instruments alcohols, bacteria, viruses, colloidal material, sugars, oils etc.

Appendix C - Water Corrosivity

LSI (Langlier Saturation Index): LSI is a method of reporting the scaling or corrosive potential of low TDS brackish water based on the level of saturation of calcium carbonate. LSI is important to boiler water and municipal plant chemists in determining whether a water is corrosive (has a negative LSI) or will tend to scale calcium carbonate (has a positive LSI). LSI is important to RO chemists as a measurement of the scaling potential for calcium carbonate. The LSI value is calculated by subtracting the calculated pH of saturation of calcium carbonate from the actual feed pH. Calcium carbonate solubility decreases with increasing temperature (as evidenced by the liming of a teakettle), higher pH, higher calcium concentration, and higher alkalinity levels. The LSI value can be lowered by reducing pH by the injection of an acid (typically sulfuric or hydrochloric) into the RO feed water. A recommended target LSI in the RO concentrate is negative 0.2 (which indicates that the concentrate is 0.2 pH units below the point of calcium carbonate saturation). A negative 0.2 LSI allows for pH excursions in actual plant operation. A polymer-based antiscalant can also be used to inhibit the precipitation of calcium carbonate. Some antiscalant suppliers have claimed the efficacy of their product up to a positive LSI value of 2.5 in the RO concentrate (through a more conservative design LSI level is +1.8).

According to Reverse Osmosis, A Practical Guide for Industrial Users (Byrne), LSI is estimated as the difference between the current pH of the water (pH) and the pH at which calcium carbonate reaches saturation (pHLSI).

The following link will take you to the American Water Works Association website and a calculator that can be used to calculate two useful corrosion indices: The Langlier Saturation Index and the Ryznar Stability Index.

<http://www.awwa.org/Resources/RTWCorrosivityCalc.cfm?navItemNumber=1576>

Limited Warranty

The Manufacturer is referred to herein as "Manufacturer", "we", "us", or "our" and the purchaser is referred to herein as "Buyer" or "you". This Limited Warranty is applicable to the HighPure Reverse Osmosis System (the "Product").

Warranty Terms

Subject to the terms and conditions set forth herein, Manufacturer warrants to the original Buyer that the Product, as manufactured by us is and will be free of defects in material and workmanship for twelve (12) months from the Warranty Commencement Date (as defined below) when used in strict accordance with the applicable operating instructions and manual and within the range of the operating conditions specified by us for the Product. This Warranty does not extend to equipment or components manufactured by others into which our Product has been incorporated or to equipment or components which have been incorporated into our Product, but if allowable, we will assign to you any such warranty made by the manufacturer of such equipment or component. This Warranty does not cover disposable items such as fuses, lamps, filters, cartridges, reverse osmosis membranes or other disposable items, which must be replaced periodically under normal and foreseeable operating conditions of the Product.

Warranty Commencement Date

The Warranty Commencement Date for the Product shall be the later of the date of: (1) receipt by you or (2) the date of installation, provided that such installation must occur within three (3) months of shipment from our facility. In no event shall the Warranty Commencement Date exceed three (3) months from the date of shipment from our manufacturing facility. You shall provide proof of purchase in order to exercise the rights granted under this Warranty. If we request, you must also provide proof of the installation date. Proof of the installation date can be made by providing us with a completed copy of the Installation & Start-Up Checklist supplied with the Product and signed by the authorized Product installer.

Warranty Service

OUR SOLE OBLIGATION UNDER THIS WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT, AT OUR OPTION, OF THE PRODUCT OR PART THEREOF, PROVED TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP DURING THE WARRANTY PERIOD. You, at your risk and expense, shall be responsible for returning the defective Product or component(s), upon obtaining a Return Goods Authorization (RGA) number from us, freight prepaid, insured and in conformance with any special packaging and shipping instructions set forth in the operating documentation or RGA instructions, or as otherwise reasonably required, to the address provided to you, together with (1) the RGA number issued by us at your request; (2) proof of purchase and, if necessary, proof of installation date; (3) a description of the suspected defects; (4) the serial number of the Product alleged to be defective; and (5) a description of the type of water pretreatment equipment that has been utilized in connection with the Product, if any. We shall, in our sole and reasonable discretion, determine whether a returned Product or component is defective in material or workmanship. We will pay the outbound freight (but not express freight) for any replacement Product or component that we ship to you in fulfillment of our obligations under this Warranty. In an emergency situation, as determined by us, we will, at our option, forward replacement Product or components to you without requiring an RGA for the questionable part(s); provided, however that you shall: (i) issue a purchase order or other payment guarantee prior to shipment; and (ii) return the questionable Product or component as soon as possible. If the questionable Product or component is found to have been misused or if the defective part is not received by us within thirty (30) days of the date you first notify us of the issue, you will be invoiced for the replacement Product or component (s) we provided. This Warranty does not cover or include labor or any travel related to the repairs. Charges will be made for our usual and customary costs and associated expenses incurred in providing Warranty Service at any location other than our factory and we reserve the right to precondition travel to your premises on prepayment of our anticipated costs.

Voiding of Warranty

This Warranty shall be void and unenforceable as to any Product which has been damaged by accident, mishandling, or misuse or has been repaired, modified, altered, disassembled or otherwise tampered with by anyone other than us or an authorized service representative. This Warranty shall be void and unenforceable if any unauthorized replacement part has been used or if the Product has not been installed, operated and maintained in strict accordance with the Product operating documentation and manuals. Any representation or performance metrics set forth in the Product operating documentation shall be void and unenforceable unless the feed water requirements set forth in the Product operating documentation are strictly adhered to.

Limitations and Exclusions

THIS WARRANTY AND THE REMEDIES DESCRIBED HEREIN ARE EXCLUSIVE AND ARE IN LIEU OF ANY AND ALL OTHER WARRANTIES OR REMEDIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO LIABILITY FOR CONSEQUENTIAL DAMAGES. To the maximum extent permitted by law, in no event shall we be liable for any damages whatsoever (including without limitation, loss of time, inconvenience, expenses such as telephone calls, labor or material charges) incurred in connection with the removal or replacement of the Product or component(s), special, incidental, consequential, or indirect damages for loss of business profits, business interruption, loss of business information, or any other pecuniary loss arising out of the use of or inability to use the Product or component (s), even where advised of the possibility of such damages. In any case, our entire liability under any provision of this Limited Warranty shall be limited to the amount actually paid by you for the Product or component(s). **PLEASE NOTE:** Certain of the above limitations or exclusions may not apply where prohibited by applicable state law.

WARRANTIES OR REPRESENTATIONS BY OTHERS.

No dealer, distributor or other person has any authority to make any warranties or representations concerning us or the Product or components. Accordingly, we are not responsible for any such warranties or representations. NO PERSON HAS ANY AUTHORITY TO BIND US TO OTHER THAN WHAT IS SET FORTH ABOVE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION. THE PARTIES RECOGNIZE AND AGREE THAT IN ALL RESPECTS, THE LAWS OF THE STATE OF MINNESOTA SHALL GOVERN THIS LIMITED WARRANTY.

Operation Log Sheet

Company Name		Company Location		Model Number		Serial Number	
Date Installed:		Date:					
		Time:					
		Units					
Prefilter Pressure (psi or Kg/cm ²): P ₁							
Postfilter Pressure (psi or Kg/cm ²): P ₂							
ΔP Cartridge Filter (psi or Kg/cm ²): P ₁ -P ₂							
Membrane Feed Pressure (psi or Kg/cm ²)							
Concentrate Pressure (psi or Kg/cm ²)							
Feed Water Temperature (°F or °C)							
Permeate Flow (gpm or m ³ /h): PER							
Concentrate Flow (gpm or m ³ /h): CON							
Recycle Flow (gpm or m ³ /h)							
Recovery [PER/(PER + CON)] x 100%							
Feed TDS (ppm)							
Concentrate TDS (ppm)							
Permeate TDS (ppm)							
Cartridge Filter Changed (Yes = √)							
Membrane Cleaned (Yes = √) Method Used							
Total Chlorine/Chloramine (ppm)							
Feedwater Hardness (gpg or ppm)							
pH							
Operator Name:							

Guidelines:

1. Record start-up data after 10 hours.

2. Log new data every week.

3. Change prefilter when the ΔP has doubled or increased by 6 psi, whichever is less.

4. Postfilter pressure must be ≥ 40 psi dynamic.

5. Membranes should be cleaned when permeate flow drops by 10%.

6. When contacting Technical Support, copies of Operation Log Sheets as well as Installation and Start-up Checklists should be E-mailed or sent before making contact.
- Make copies of blank Log Sheet for future use.



Pentair Water

Commercial & Industrial Purity Solutions

220 Park Drive
Chardon, OH USA 44024
Customer Care - 877.261.2257
Customer.ServiceCIPS@Pentair.com
Technical and Application Support - 877.372.8265
Tech.SupportCIPS@Pentair.com